

# MUX expansion module

FPE-7039



**BOSCH**

## Installation manual

**en** english

**es-AR** español

**pt-BR** português



<b>en</b> english	Notices	<b>4</b>
<b>es-AR</b> español	Avisos	<b>21</b>
<b>pt-BR</b> português	Avisos	<b>32</b>

# 1 Notices

These instructions cover the installation of the FPE-7039 Multiplex Expansion Module in a fire system supervised by an FPD-7024 Fire Alarm Control Panel (FACP).

## **Open Source Software information**

---



### **Notice!**

For general information regarding open source software in Bosch Security Systems please visit <http://www.boschsecurity.com/oss>

---

This product may contain the following open source components:

BSD 3-clause "New" or "Revised" License:

- ARM CMSIS (limited to CMSIS/Include directory) (4.00)
- ProtoThreads (1.4)

STMicroelectronics software license agreement liberty v2:

- STM32F10x StdPeriphDriver (3.6.1)

=====  
License Texts  
=====

Component: ARM CMSIS (limited to CMSIS/Include directory)

Version: 4.00

URL: <http://www.arm.com/>

License Type: BSD 3-clause "New" or "Revised" License

/\* Copyright (c) 2009 - 2014 ARM LIMITED

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of ARM nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

\*

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL COPYRIGHT HOLDERS AND CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

-----\*/

-----  
Component: ProtoThreads  
Version: 1.4  
URL: <http://dunkels.com/adam/pt/>  
License Type: BSD 3-clause "New" or "Revised" License

Copyright (c) 2004-2005, Swedish Institute of Computer Science.  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of the Institute nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE INSTITUTE AND CONTRIBUTORS 'AS IS' AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE INSTITUTE OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

-----

Component: STM32F10x StdPeriphDriver  
Version: 3.6.1  
URL: <http://www.st.com/>  
License Type: STMicroelectronics software license agreement liberty v2

#### SOFTWARE LICENSE AGREEMENT

By using this Licensed Software, You are agreeing to be bound by the terms and conditions of this License Agreement.

Do not use the Licensed Software until You have read and agreed to the following terms and conditions.

The use of the Licensed Software implies automatically the acceptance of the following terms and conditions.

**DEFINITIONS**

Licensed Software: means the enclosed SOFTWARE/FIRMWARE, EXAMPLES, PROJECT TEMPLATE and all the related documentation and design tools licensed and delivered in the form of object and/or source code as the case maybe.

Product: means Your and Your's end-users' product or system, and all the related documentation, that includes or incorporates the Licensed Software and provided further that such Licensed Software or derivative works of the Licensed Software execute solely and exclusively on microcontroller devices manufactured by or for ST.

**LICENSE**

STMicroelectronics ("ST") grants You a non-exclusive, worldwide, non-transferable (whether by assignment or otherwise unless expressly authorized by ST) non sub-licensable, revocable, royalty-free limited license of the Licensed Software to:

- (i) make copies, prepare derivative works of the source code version of the Licensed Software for the sole and exclusive purpose of developing versions of such Licensed Software only for use within the Product;
- (ii) make copies, prepare derivative works of the object code versions of the Licensed Software for the sole purpose of designing, developing and manufacturing the Products;
- (iii) make copies, prepare derivative works of the documentation part of the Licensed Software (including non confidential comments from source code files if applicable), for the sole purpose of providing documentation for the Product and its usage;
- (iv) make, have made, use, sell, offer to sell, import and export or otherwise distribute Products also through multiple tiers.

**OWNERSHIP AND COPYRIGHT**

Title to the Licensed Software, related documentation and all copies thereof remain with ST and/or its licensors. You may not remove the copyrights notices from the Licensed Software and to any copies of the Licensed Software. You agree to prevent any unauthorized copying of the Licensed Software and related documentation.

**RESTRICTIONS**

Unless otherwise explicitly stated in this Agreement, You may not sell, assign, sublicense, lease, rent or otherwise distribute the Licensed Software for commercial purposes, in whole or in part. You acknowledge and agree that any use, adaptation, translation or transcription of the Licensed Software or any portion or derivative thereof, for use with processors manufactured by or for an entity other than ST is a material breach of this Agreement and requires a separate license from ST.

No source code relating to and/or based upon Licensed Software is to be made available or sublicensed by You unless expressly permitted under the Section "License".

You acknowledge and agree that the protection of the source code of the Licensed Software warrants the imposition of reasonable security precautions. In the event ST demonstrates to You a reasonable belief that the source code of the Licensed Software has been used or distributed in violation of this Agreement, ST may, by written notification, request certification as to whether such unauthorized use or distribution has occurred. You shall cooperate and assist ST in its determination of whether there has been unauthorized use or distribution of the source code of the Licensed Software and will take appropriate steps to remedy any unauthorized use or distribution.

#### NO WARRANTY

The Licensed Software is provided "as is" and "with all faults" without warranty of any kind expressed or implied. ST and its licensors expressly disclaim all warranties, expressed, implied or otherwise, including without limitation, warranties of merchantability, fitness for a particular purpose and noninfringement of intellectual property rights. ST does not warrant that the use in whole or in part of the Licensed Software will be interrupted or error free, will meet your requirements, or will operate with the combination of hardware and software selected by You. You are responsible for determining whether the Licensed Software will be suitable for your intended use or application or will achieve your intended results. ST will not be liable to You and/or to any third party for the derivative works of the Licensed Software developed by You.

ST has not authorised anyone to make any representation or warranty for the Licensed Software, and any technical, applications or design information or advice, quality characterization, reliability data or other services provided by ST shall not constitute any representation or warranty by ST or alter this disclaimer or warranty, and in no additional obligations or liabilities shall arise from ST's providing such information or services. ST does not assume or authorize any other person to assume for it any other liability in connection with its Licensed Software.

Nothing contained in this Agreement will be construed as:

- (i) a warranty or representation by ST to maintain production of any ST device or other hardware or software with which the Licensed Software may be used or to otherwise maintain or support the Licensed Software in any manner; and
  - (ii) a commitment from ST and/or its licensors to bring or prosecute actions or suits against third parties for infringement of any of the rights licensed hereby, or conferring any rights to bring or prosecute actions or suits against third parties for infringement. However, ST has the right to terminate this Agreement immediately upon receiving notice of any claim, suit or proceeding that alleges that the Licensed Software or your use or distribution of the Licensed Software infringes any third party intellectual property rights.
- All other warranties, conditions or other terms implied by law are excluded to the fullest extent permitted by law.



**LIMITATION OF LIABILITIES**

In no event ST or its licensors shall be liable to You or any third party for any indirect, special, consequential, incidental, punitive damages or other damages (including but not limited to, the cost of labour, re-qualification, delay, loss of profits, loss of revenues, loss of data, costs of procurement of substitute goods or services or the like) whether based on contract, tort, or any other legal theory, relating to or in connection with the Licensed Software, the documentation or this Agreement, even if ST has been advised of the possibility of such damages.

In no event shall ST's liability to You or any third party under this Agreement, including any claim with respect of any third party intellectual property rights, for any cause of action exceed 100 US\$. This section does not apply to the extent prohibited by law. For the purposes of this section, any liability of ST shall be treated in the aggregate.

**TERMINATION**

ST may terminate this License Agreement license at any time if You are in material breach of any of its terms and conditions and You have failed to cure such breach within 30 (thirty) days upon occurrence of such breach. Upon termination, You will immediately destroy or return all copies of the Licensed Software and documentation to ST. After termination, You will be entitled to use the Licensed Software used into Products that include microcontroller devices manufactured by or for ST, purchased by You before the date of the breach.

**APPLICABLE LAW AND JURISDICTION**

In case of dispute and in the absence of an amicable settlement, the only competent jurisdiction shall be the Courts of Geneva, Switzerland. The applicable law shall be the law of Switzerland.

**SEVERABILITY**

If any provision of this agreement is or becomes, at any time or for any reason, unenforceable or invalid, no other provision of this agreement shall be affected thereby, and the remaining provisions of this agreement shall continue with the same force and effect as if such unenforceable or invalid provisions had not been inserted in this Agreement.

**WAIVER**

The waiver by either party of any breach of any provisions of this Agreement shall not operate or be construed as a waiver of any other or a subsequent breach of the same or a different provision.

**ASSIGNMENT**

This Agreement may not be assigned by You, nor any of Your rights or obligations hereunder, to any third party without prior written consent of the other party (which shall not be unreasonably withheld). In the event that this Agreement is assigned effectively to a third party, this Agreement shall bind upon successors and assigns of the parties hereto.

**RELATIONSHIP OF THE PARTIES**

Nothing in this Agreement shall create, or be deemed to create, a partnership or the relationship of principal and agent or employer and employee between the Parties. Neither Party has the authority or power to bind, to contract in the name of or to create a liability for the other in any way or for any purpose.

**Regulatory and safety**

Before installing the module, become familiar with the *Installation and Operation Guide* for the control panel you are using.

Install, test and maintain the module according to these instructions, NFPA codes, local codes, and the authority having jurisdiction (AHJ). Failure to follow these instructions can result in failure of a detector to initiate an alarm event. Bosch Security Systems, Inc. is not responsible for improperly installed, tested or maintained devices.

**Warning!**

Follow these instructions to avoid personal injury and damage to equipment.

---

NFPA 72 requires that you perform a complete system wide functional test following any modifications, repair, upgrades or adjustments made to the system's components, hardware, wiring, programming and software/firmware.

## 2 Description

The FPE-7039 MUX expansion module is designed to enhance the conventional features of the D7024 or FPD-7024/DS9400 Fire alarm control panels (FACPs). The module connects directly to the FACP for either two Class B multiplex buses or one Class A multiplex bus. When installed as two Class B multiplex buses, you can program addresses 9 through 255. When installed as one Class A multiplex bus, you can program addresses 9 through 128.

The module also increases the number of relay outputs (to 58 on the D7024/DS9400 control panels and 59 on FPD-7024 control panels). It adds an additional 400 events to the history buffer for a total of 499 non-volatile events. It also allows for up to 100 system users (an addition of 84 PINs from the base system).

The module can be programmed remotely from a PC using RPS Remote programming software.

The module can be used with the Bosch Security Systems, Inc. control panels and modules indicated in the following table.

<b>Control panels</b>	
<b>Active:</b>	FPD-7024 Fire alarm control panels
<b>Legacy:*</b>	D7024 Fire alarm control panels
	DS9400 Control panels
<b>Modules</b>	
<b>Active:</b>	D7042 Multiplex eight-input remote module
	D7042B Multiplex eight-input remote module with enclosure
	D7044 Multiplex single-input module
	D7044M Multiplex mini single-input module

	D7050 Addressable photoelectric smoke detector
	D7050DH Addressable photoelectric duct smoke detector head
	D7050TH Addressable photoelectric smoke/heat detector
	D7050-B6 Smoke detector base
	D7052 Multiplex dual-input module
	D7053 Multiplex Input-output module
	FLM-7024-ISO MUX bus isolator module
	FMM-7045 Multiplex addressable manual pull station
	FMM-7045-D dual-action multiplex addressable manual pull station
* Legacy products were investigated to comply only to UL864 8th edition	

### 3 Mounting



**Danger!**

Make sure all power is removed before making any electrical connections. Failure to do so may result in personal injury and/or damage to equipment.




**Caution!**

Static-sensitive components!

The FACP and modules contain static-sensitive components and must be handled with care. Follow proper antistatic handling procedures.

**FPE-7039 board mounting**




**Figure 3.1: Mounting the FPE-7039**

1	FPE-7039	2	FACP
3	Mounting holes (4) for plastic standoffs	4	FACP connector pins (align with FPE-7039)
5	Mounting screw	6	Ground wire

If the FACP (see callout 2 in above figure) is already installed in an enclosure, remove it.

1. Place the FACP on a flat surface with the component side facing up.
2. Insert the four plastic standoffs in the mounting holes (callout 3 above) without bending or flexing the FACP.
3. Align the standoff tabs so they do not touch the module components.
4. Firmly press the standoffs into the board, allowing the ears to expand out.
5. Mount the board (callout 1 above) on the standoffs ensuring the connector pins (callout 4 above) are properly aligned.
6. Install the FACP in the enclosure.
7. Use the mounting screw (callout 5 above) to secure the FPE-7039's ground wire (callout 6 above) to the FACP.

### I/O module mounting



**Figure 3.2: Mounting the FPE-7039 I/O module**

1	FACP enclosure	2	FPE-7039 I/O module
3	Plastic standoffs (3)	4	4-wire (red, black, yellow, green) harness

5	Connector terminal plug	6	Yellow/green wire connecting the I/O module to the FACP ground terminal
---	-------------------------	---	---

If the FPE-7039 board is not mounted to the FACP board, mount it using the instructions above.

1. Insert the three plastic standoffs (see callout 3 in the above figure) in the mounting holes in the enclosure.
2. Mount the I/O module (callout 2 above) in the FACP enclosure (callout 1 above).
3. Connect the wire harness of the I/O module to the terminal on the FPE-7039 (callout 5 above).
4. Connect the yellow and green earth ground wire (callout 6 above) to the FACP 's earth ground terminal.

## 4 Wiring

You can configure the FPE-7039 with a single fault tolerant Class A loop or as a pair of supervised Class B branches. For programming information, see the *FPD-7024 Installation and Operation Guide (IOG)*.

### 4.1 Determining system limits

**Notice!**

Do **not** use shielded wire. Twisted-pair wire is not recommended, but is acceptable if wire length is reduced by 50%.


**Notice!**

In the following graphs,

- a) data points falling in the light area are acceptable.
- b) data points falling in the middle area depend on your configuration. They must be verified with the battery calc table.
- c) data points falling in the dark area require changes in wire length or size, number of devices, or configuration.

1. Find the intersection of the desired number of devices and wire length/resistance you want on the first graph below. If the data point falls in the light area, note the available wire sizes (AWG or ISO) for your installation. Then go to the next step.  
If it does not, see the Notice above.
2. Look up the capacitance for the specific wire size/length/type.
3. Check the intersection point of the capacitance and number of devices on the second chart below. If the data point falls in the light area, your choices are acceptable. If not, see the Notice above.






<b>Maximum wire length</b>	
Maximum wire resistance	50 Ω at +20°F (+68°C), depends on method and wire size used
Wire length	5950 ft. (1810 m), depends on wire size and number of devices
Wire capacitance*	<0.12 μF (maximum per bus), depends on wire size and number of devices

<b>Maximum wire length</b>
* This table gives capacitance in microFarads ( $\mu\text{F}$ ), but the graph gives it in nanoFarads (nF). For example, 0.12 $\mu\text{F}$ = 120 nF.

## 4.2 Wiring the loops

Determine the appropriate configuration (number and type of devices and wire size and length).

1. Run solid wire from the FACP to the device locations and connect the multiplex loop.




**Figure 4.1: Wiring Class A loops and Class B branches**

1	I/O module wired as Class A	2	Wiring harness
3	Ground wire	4	Class A loop (addresses 9 to 128)
5	I/O module wired as Class B	6	Wiring harness
7	Ground wire	8	Class B branch (addresses 129 to 255)
9	Class B branch (addresses 9 to 128)		
All MUX terminals are power-limited and supervised			

2. Ensure the loop is disconnected from the FPE-7039 Module.
3. Measure loop resistance by shorting: the end of the farthest device in Class B.


the return wire in Class A.

4. Read the total resistance of all wires associated with the loop.



**Figure 4.2: Measuring Class B loop resistance**

1	50 Ω maximum	2	MUX bus wires
3	Clip lead		



**Figure 4.3: Measuring Class A loop resistance**

1	50 Ω maximum	2	MUX bus wires
3	Clip lead		

## 5 Specifications

### Environmental

Environment	Indoor, dry
-------------	-------------

### Power

<b>Current Draw</b>	
Alarm	190 mA maximum
Load, Class A	100 mA maximum
Load, Class B	100 mA maximum for each bus
Standby	190 mA maximum
Bus Voltage	8.5 V to 13 V
Wire Resistance (maximum)	50 $\Omega$ Class A or Class B

# 1 Avisos

Estas instrucciones abarcan la instalación del Módulo de Expansión Multiplex FPE-7039, en un sistema contra incendios supervisado por un Panel de Control de Alarma de Incendio (FACP) FPD-7024.

Antes de instalar el módulo, familiarícese con la *Guía de Instalación y Operación* para el panel de control que está utilizando.

Instale, pruebe y mantenga el módulo de acuerdo con estas instrucciones, los códigos de NFPA, los códigos locales y la Autoridad con Jurisdicción (AHJ). En caso de no seguir estas instrucciones, pueden producirse fallas en un detector que inicie un evento de alarma. Bosch Security Systems, Inc. no se hace responsable de la instalación, prueba o mantenimiento incorrecto de los dispositivos.



## **Aviso!**

Siga estas instrucciones para evitar daños personales y daños al equipo.

Según la norma NFPA 72, es necesario usted lleve a cabo una prueba de funcionamiento de todo el sistema luego de realizar cualquier modificación, reparación, actualización o ajuste en los componentes, hardware, cableado, programación, software o firmware del sistema.

## **Información del software de código abierto**



## **Nota!**

Para obtener información general con respecto al software de código abierto en Bosch Security Systems visite <http://www.boschsecurity.com/oss>

## 2 Descripción

El Módulo de expansión FPE-7039 MUX está diseñado para mejorar las características convencionales de los paneles de control de alarma de incendio (FACP) D7024 o FPD-7024/DS9400 (FACP). El módulo se conecta directamente al FACP a dos bus múltiples clase B o un bus múltiple clase A. Cuando se instalan como dos bus múltiples de clase B, puede programar las direcciones 9 a 255. Cuando se instalan como un bus múltiple clase A, puede programar las direcciones 9 a 128.

El módulo además aumenta la cantidad de salidas de relé (a 58 en los paneles de control D7024/DS9400 y 59 en paneles de control FPD-7024). Agrega 400 eventos adicionales a la memoria intermedia histórica para un total de 499 eventos permanentes. Además permite hasta 100 usuarios de sistema (84 PIN adicionales del sistema base).

El módulo se puede programar de manera remota desde una PC que utilice el software de programación remota RPS.

El módulo se puede utilizar con los paneles de control y módulos de Bosch Security Systems, Inc. que se enumeran en la tabla siguiente.

<b>Paneles de control</b>	
<b>Activo:</b>	Paneles de control de alarma de incendio FPD-7024
<b>Antiguo:*</b>	Paneles de control de alarmas de incendio D7024
	Paneles de Control DS9400
<b>Módulos</b>	
<b>Activo:</b>	Módulo remoto de ocho entradas múltiples D7042
	Módulo múltiple de ocho entradas D7042B con carcasa contra incendios

	Módulo de una entrada múltiple D7044
	Módulo de una entrada mini múltiple D7044M
	Cabezal del detector de humo fotoeléctrico direccionable D7050
	Cabezal del detector de humo de Ducto fotoeléctrico direccionable D7050DH
	Cabezal del detector de humo/calor fotoeléctrico direccionable D7050TH
	Base del detector de Humo D7050-B6
	Módulo de entrada doble múltiple D7052
	Módulo de entrada-salida múltiple D7053
	Módulo aislador de bus MUX FLM-7024-ISO
	Estación analógica de aviso manual direccionable múltiple FMM-7045
	Estación analógica de aviso manual direccionable múltiple de acción dual FMM-7045-D
* Se investigan los productos antiguos solo con respecto al cumplimiento de la 8.ª edición UL864	

### 3 Montaje



#### Peligro!

Asegúrese de que antes de realizar cualquier conexión eléctrica, se haya eliminado la alimentación. No hacerlo puede producir daños personales y/o a los equipos.



#### Precaución!

¡Componentes sensibles a las cargas electrostáticas!  
La FACP y los módulos tienen componentes sensibles a las cargas electrostáticas y deben manipularse con cuidado. Siga los procedimientos de manejo antiestática correspondientes.

#### Montaje del panel FPE-7039




Figura 3.1: Montaje de FPE-7039

1	FPE-7039	2	FACP
3	Orificios de montaje (4) para separadores plásticos	4	Clavijas de conexión de FACP (alinear con FPE-7039)
5	Tornillo de montaje	6	Cable de conexión a tierra



Si el FACP (consulte la índice 2 en la figura anterior) ya está instalado en un gabinete, quítelo.

1. Coloque el FACP sobre una superficie plana con el componente hacia arriba.
2. Inserte cuatros separadores de plástico en los orificios de montaje (índice 3 arriba) sin doblar o flexionar el FACP.
3. Alinee las pestañas del separador para que no toquen los componentes del módulo.
4. Presione con firmeza los separadores en el panel, para que las orejas se expandan hacia afuera.
5. Monte el panel (índice 1 arriba) en los separadores para asegurar que las clavijas de conexión (índice 4 arriba) estén correctamente alineadas.
6. Instale el FACP en el gabinete
7. Use el tornillo de montaje (índice 5 arriba) para asegurar el cable a tierra de FPE-7039 (índice 6 arriba) al FACP.

### Montaje del módulo E/S




Figura 3.2: Montaje del módulo E/S FPE-7039

1	Gabinete de FACP	2	Módulo E/S FPE-7039
---	------------------	---	---------------------

3	Separadores plásticos (3)	4	Cableado de 4 cables (rojo, negro, amarillo, verde)
5	Enchufe de terminal del conector	6	El cable amarillo/verde que conecta el módulo de E/S al terminal a tierra FACP

Si el panel FPE-7039 no está montado en el panel del FACP, montarlo siguiendo las instrucciones anteriores.

1. Inserte los tres separadores de plástico (consulte la índice 3 en la figura anterior) en los orificios de montaje en el gabinete.
2. Monte el módulo E/S (índice 2 arriba) en el gabinete del FACP (índice 1 arriba).
3. Conecte el cableado del módulo E/S al terminal en el FPE-7039 (índice 5 arriba).
4. Conecte el cable a tierra amarillo y verde (índice 6 arriba) al terminal a tierra de FACP.

## 4 Cableado

Puede configurar el FPE-7039 con un solo circuito tolerante a fallas Clase A o como un par de ramales supervisados Clase B. Para obtener información sobre programación, consulte la *Guía de Instalación y Operación FPD-7024 (IOG)*.

### 4.1 Determinación de los límites del sistema

**Nota!**

**No** utilice cables blindados. El cable de par trenzado no es recomendado, pero es aceptable si se reduce un 50% la longitud del cable.


**Nota!**

En los siguientes gráficos,

- los puntos de datos del área clara son aceptables.
- los puntos de datos del área del medio dependen de su configuración. Deben ser verificados con la tabla de cálculo de batería.
- los puntos de datos del área oscura requieren cambios en la longitud o el tamaño del cable, la cantidad de dispositivos o la configuración.

- Encuentre la intersección de la cantidad deseada de dispositivos y la longitud/resistencia del cable que desea en el primer gráfico a continuación.  
Si los puntos de datos se encuentran en el área clara, tenga en cuenta los tamaños de cable (AWG o ISO) disponibles para su instalación. Luego, continúe al siguiente paso.  
De lo contrario, consulte la Notificación arriba.
- Busque la capacitancia para el calibre/longitud/tipo de cable específico.

3. Controle el punto de intersección de la capacitancia y la cantidad de dispositivos en el segundo gráfico a continuación. Si los puntos de datos están en el área clara, sus opciones son aceptables. De lo contrario, consulte la Notificación arriba.




<b>Longitud máxima del cable</b>	
Resistencia máxima del cable	50 Ω a +20 °F (+68 °C), según el método y el tamaño del cable que se utilicen
Longitud del cable	5950 ft. (1810 m), según el calibre del cable y la cantidad de dispositivos

<b>Longitud máxima del cable</b>	
Capacitancia del cable*	<0,12 $\mu$ F (máximo por bus), según el tamaño del cable y la cantidad de dispositivos
* Esta tabla muestra la capacitancia en microfaradios ( $\mu$ F), pero el gráfico provee nanofaradios (nF). Por ejemplo, 0,12 $\mu$ F = 120 nF.	

## 4.2 Cableado de los lazos

Determine la configuración correspondiente (cantidad y tipo de dispositivos y tamaño y longitud del cable).

1. Coloque cables sólidos del FACP a las ubicaciones de los dispositivos y conecte el lazo múltiple.




**Figura 4.1: Cableado de lazos Clase A y ramales Clase B**

1	Módulo E/S cableado como Clase A	2	Cableado
3	Cable de conexión a tierra	4	Lazo Clase A (direcciones 9 a 128)
5	Módulo E/S cableado como Clase B	6	Cableado
7	Cable de conexión a tierra	8	Ramal Clase B (direcciones 129 a 255)
9	Ramal Clase B (direcciones 9 a 128)		


todos los terminales MUX son de alimentación limitada y supervisadas

2. Asegúrese que el lazo esté desconectado del Módulo FPE-7039.
3. Medición de la resistencia del lazo por circuito: el final del último dispositivo en la Clase B. el cable de retorno en la Clase A.
4. Lea la resistencia total de todos los cables asociados al lazo.



**Figura 4.2: Medición de la resistencia del lazo de Clase B**

1	50 $\Omega$ máximo	2	Cables del bus MUX
3	Pinza		



**Figura 4.3: Medición de la resistencia del lazo de Clase A**

1	50 $\Omega$ máximo	2	Cables del bus MUX
3	Pinza		

## 5 Especificaciones

### Condiciones ambientales

Entorno	Interior, seco
---------	----------------

### Alimentación

<b>Consumo de corriente</b>	
Alarma	190 mA máximo
Carga, Clase A	100 mA máximo
Carga, Clase B	100 mA máximo para cada bus
En reposo	190 mA máximo
Tensión del bus	De 8.5 V a 13 V
Resistencia del cable (máxima)	50 $\Omega$ Clase A o Clase B

# 1 Avisos

Estas instruções abrangem a instalação do FPE-7039 Módulo de expansão multiplex em um sistema de incêndio supervisionado por um Painel de controle de alarmes de incêndio (FACP) FPD-7024.

Antes de instalar o módulo, leia o *Manual de instalação e operação* do painel de controle que você está usando. Instale, teste e mantenha o módulo de acordo com estas instruções, os códigos NFPA, os códigos locais e a autoridade com jurisdição (AHJ). O não cumprimento destas instruções pode resultar no funcionamento incorreto do detector para iniciar um evento de alarme. A Bosch Security Systems, Inc. não se responsabiliza por dispositivos instalados, testados ou mantidos incorretamente.



## **Aviso!**

Siga estas instruções para evitar danos pessoais e no equipamento.

---

O NFPA 72 exige que você faça um teste funcional completo, abrangendo todo o sistema após quaisquer modificações, reparos, upgrades ou ajustes efetuados nos componentes do sistema, hardware, cabeamento, programação e software/firmware.

## **Informações de softwares de código aberto**



## **Nota!**

Para obter informações gerais sobre softwares de código aberto na Bosch Security Systems, acesse <http://www.boschsecurity.com/oss>



## 2 Descrição

O FPE-7039 Módulo de expansão foi projetado para aprimorar os recursos convencionais dos Painéis de controle de alarme de incêndio (FACPs) D7024 ou FPD-7024/DS9400. O módulo se conecta diretamente ao FACP para dois barramentos multiplex Classe B ou um barramento multiplex Classe A. Quando instalado como dois barramentos multiplex classe B, você pode programar os endereços 9 a 255. Quando instalado como um barramento multiplex classe A, você pode programar os endereços 9 a 128.

O módulo também aumenta a quantidade de saídas de relé (para 58 nos painéis de controle D7024/DS9400 e 59 nos painéis de controle FPD-7024). Ele acrescenta 400 eventos adicionais ao buffer do histórico para um total de 499 eventos não voláteis. Ele também permite até 100 usuários no sistema (aumento de 84 PINs no sistema básico).

O módulo pode ser programado remotamente a partir de um PC usando o Software de programação remota RPS.

O módulo pode ser usado com os painéis de controle da Bosch Security Systems, Inc. e com os módulos indicados na tabela a seguir.

<b>Painéis de controle</b>	
<b>Ativo:</b>	Painéis de controle de alarmes de incêndio FPD-7024
<b>Herdados:*</b>	Painéis de controle de alarmes de incêndio D7024
	Painéis de controle DS9400
<b>Módulos</b>	
<b>Ativo:</b>	D7042 Módulo remoto de oito entradas Multiplex

	D7042B Módulo remoto de oito entradas Multiplex com gabinete
	D7044 Módulo monitor de uma entrada multiplex
	D7044M Minimódulo monitor de uma entrada multiplex
	D7050 Detector fotoelétrico de fumaça endereçável
	D7050DH Cabeça de detector de fumaça fotoelétrico para duto endereçável
	D7050TH Detector fotoelétrico de fumaça/ temperatura endereçável
	D7050-B6 Base do detector de fumaça
	D7052 Módulo monitor de entrada dupla multiplex
	D7053 Módulo de entrada-saída multiplex
	FLM-7024-ISO módulo isolador de barramento MUX
	FMM-7045 Acionador manual analógico endereçável multiplex
	FMM-7045-D Acionador manual analógico endereçável multiplex de ação dupla
* Os produtos herdados estão em conformidade somente com a UL864 8ª edição	

### 3 Instalação



#### Perigo!

Certifique-se de que toda a energia foi removida antes de fazer qualquer conexão elétrica. O contrário pode resultar em danos pessoais e/ou ao equipamento.



#### Cuidado!

Componentes sensíveis à estática!

O FACP e os módulos contêm componentes sensíveis à estática e devem ser manuseados com cuidado. Siga os procedimentos adequados de manuseio antiestático.

#### FPE-7039 instalação da placa




Figura 3.1: Montagem da FPE-7039

1	FPE-7039	2	FACP
3	Furos de montagem (4) para espaçadores de plástico	4	Pinos conectores do FACP (alinhar com FPE-7039)
5	Parafuso de montagem	6	Fio terra

Se o FACP (consulte a legenda 2 na figura acima) já estiver instalado em um gabinete, remova-o.

1. Coloque o FACP em uma superfície plana com o lado do componente voltado para cima.
2. Insira os quatro espaçadores de plástico nos furos de montagem (legenda 3 acima) sem dobrar ou flexionar o FACP.
3. Alinhe as guias dos espaçadores para que elas não toquem nos componentes do módulo.
4. Pressione os espaçadores com firmeza na placa, permitindo que as orelhas se expandam.
5. Monte a placa (legenda 1 acima) nos espaçadores, garantindo que os pinos do conector (legenda 4 acima) estejam devidamente alinhados.
6. Instale o FACP no gabinete.
7. Use o parafuso de montagem (legenda 5 acima) para proteger o fio de ligação à terra do FPE-7039 (legenda 6 acima) do FACP.

### Montagem do módulo de E/S




Figura 3.2: Montagem do FPE-7039 módulo de E/S

1	Gabinete do FACP	2	FPE-7039 módulo de E/S
---	------------------	---	------------------------

3	Espaçadores de plástico (3)	4	Harness de 4 fios (vermelho, preto, amarelo, verde)
5	Plugue do terminal do conector	6	Fio amarelo/verde conectado ao módulo de E/S no terminal de aterramento do FACP.

Se a placa do FPE-7039 não for montada na placa do FACP, monte-a usando as instruções acima.

1. Insira os três espaçadores de plástico (consulte a legenda 3 na figura acima) nos furos de montagem do gabinete.
2. Monte o módulo de E/S (legenda 2 acima) no gabinete do FACP (legenda 1 acima).
3. Conecte o harness de fios do módulo de E/S ao terminal no FPE-7039 (legenda 5 acima).
4. Conecte o fio terra amarelo/verde (legenda 6 acima) ao terminal de aterramento do FACP.

## 4 Cabeamento

Você pode configurar o FPE-7039 com um único loop Classe A tolerante a falhas ou como um par de ramificações Classe B supervisionadas. Consulte o *Manual de Instalação e Operação do FPD-7024 (IOG)* para obter instruções sobre programação.

### 4.1 Determinar os limites do sistema

**Nota!**


**Não** utilize cabo blindado. Não é recomendável usar cabo de par trançado, mas é aceitável se o comprimento do cabo for reduzido em 50%.

**Nota!**

Nos gráficos a seguir,

- a) os pontos de dados que incidem na área clara são aceitáveis.
- b) os pontos de dados que incidem na área intermédia dependem da sua configuração. Eles devem ser verificados com a tabela de cálculo de bateria.
- c) pontos de dados que incidem na área escura requerem mudanças na bitola ou comprimento do cabo, número de dispositivos, ou configuração.

1. Localize a interseção entre o número desejado de dispositivos e o comprimento / resistência do cabo desejado no primeiro gráfico abaixo.  
se o ponto de dados incidir na área clara, observe as bitolas de cabos (AWG ou ISO) que estão disponíveis para a sua instalação. Em seguida, avance para a próxima etapa. caso contrário, consulte o Aviso acima.
2. Procure a capacitância para a bitola, comprimento e tipo de cabo específico.
3. Verifique o ponto de interseção entre a capacitância e o número de dispositivos no segundo gráfico abaixo. Se o ponto de dados incidir na área clara, as suas escolhas são aceitáveis. Caso contrário, consulte o Aviso acima.



<b>Comprimento máximo do cabo</b>	
Resistência máxima do cabo	50 Ω a +68 °C (+20 °F), depende do método e bitola de cabo usados
Comprimento do cabo	1810 m (5950 pés), depende da bitola do fio e número de dispositivos
Capacitância do cabo*	<0,12 μF (máximo por barramento), depende da bitola do cabo e número de dispositivos


### Comprimento máximo do cabo

\* Esta tabela apresenta a capacitância em microFarads ( $\mu\text{F}$ ), mas o gráfico a informa em nanoFarads (nF). Por exemplo,  $0,12 \mu\text{F} = 120 \text{nF}$ .

## 4.2 Cabeamento dos loops

Determinar a configuração adequada (número e tipo de dispositivos, bitola e comprimento do cabo).

1. Passar fio sólido do FACP até as localizações dos dispositivos e conectar o loop multiplex.



**Figura 4.1: Loops Classe A e ramificações Classe B de cabeamento**


1	Módulo E/S cabeado como Classe A	2	Chicote de cabos do cabeamento
3	Fio terra	4	Loop Classe A (endereços de 9 a 128)
5	Módulo E/S cabeado como Classe B	6	Chicote de cabos do cabeamento
7	Fio terra	8	Ramificação Classe B (endereços de 129 a 255)
9	Ramificação Classe B (endereços de 9 a 128)		
Todos os terminais MUX têm limitação de potência e são supervisionados.			

2. Assegure-se que o loop está desconectado do módulo FPE-7039.
3. Medição da resistência do loop através de curto-circuito:




a extremidade do dispositivo mais distante na Classe B.  
o cabo de retorno na Classe A.

4. Ler a resistência total de todos os cabos associados ao loop.



**Figura 4.2: Medição da resistência do loop Classe B**

1	Máximo de 50 Ω	2	Cabos de barramento MUX
3	Cabo-pinça		



**Figura 4.3: Medição da resistência do loop Classe A**

1	Máximo de 50 Ω	2	Cabos de barramento MUX
3	Cabo-pinça		

## 5 Especificações

### Ambiental

Ambiente	Interno, seco
----------	---------------

### Alimentação

Carga de alarme do <b>consumo de corrente</b> , carga Classe A, em repouso Classe B	máximo de 190 mA máximo de 100 mA máximo de 100 mA para cada barramento máximo de 190 mA
Tensão do barramento	8,5 V a 13 V
Resistência do cabo (máxima)	50 $\Omega$ Classe A ou Classe B



**Bosch Security Systems, Inc.**

130 Perinton Parkway  
Fairport, NY 14450  
USA

**[www.boschsecurity.com](http://www.boschsecurity.com)**

© Bosch Security Systems, Inc., 2016

**Bosch Sicherheitssysteme GmbH**

Robert-Bosch-Ring 5  
85630 Grasbrunn  
Germany