

MEITRACK SMS Protocol

For MT90

**MVT100/MVT340/MVT380/MVT600/T1/T3/
T333/MVT800/T322X/TC68S/T355/T311/P66**

Change History

File Name	MEITRACK SMS Protocol	Created By	Renny Lee
Project	MT90/MVT100/MVT340/MVT380/MVT600/T1/T3/ T333/MVT800/T322X/TC68S/T355/T311/P66	Creation Date	2010-07-31
		Update Date	2015-04-15
Subproject	SMS Protocol	Total Pages	29
Version	V2.0	Confidential	Internal Documentation

Contents

1 Command Format.....	- 5 -
1.1 SMS Command Format.....	- 5 -
1.2 Event Code and SMS Header	- 6 -
2 Command List.....	- 7 -
3 Command Details	- 9 -
3.1 Real-Time Location Query – A00	- 9 -
3.2 Track by Time Interval (SMS) – A02	- 9 -
3.3 Real-Time Longitude and Latitude Query – A10	- 10 -
3.4 Track by Time Interval (GPRS) – A12	- 10 -
3.5 Setting the Direction Change Report Function – A13	- 10 -
3.6 Track by Distance – A14	- 11 -
3.7 Setting the Parking Scheduled Tracking Function – A15	- 11 -
3.8 Enabling the Parking Scheduled Tracking Function – A16.....	- 12 -
3.9 Enabling or Disabling the RFID Control OUT1 Function (MVT600/T1/T333/T3) – A17.....	- 12 -
3.10 3D-Shake Wake Up (MT90) – A19.....	- 13 -
3.11 Setting GPRS Parameters – A21	- 13 -
3.12 Setting the DNS Server IP Address – A22.....	- 13 -
3.13 Setting the Standby GPRS Server – A23.....	- 14 -
3.14 Setting a Man Down Alarm – A29.....	- 14 -
3.15 Setting Roaming and Track by Time Interval – A55.....	- 15 -
3.16 Reading All Authorized Phone Numbers – A70.....	- 16 -
3.17 Setting a Combined Function Phone Number – A71	- 16 -
3.18 Setting a Listen-in Phone Number – A72	- 17 -
3.19 Setting the Smart Sleep Mode – A73	- 17 -
3.20 Querying the SIM Card Balance – A75	- 18 -
3.21 Setting a Geo-Fence – B05.....	- 19 -
3.22 Deleting a Geo-Fence – B06.....	- 19 -
3.23 Setting the Speeding Alarm Function – B07	- 20 -
3.24 Setting the Towing Alarm Function – B08.....	- 20 -
3.25 Setting the Anti-Theft Function – B21	- 21 -
3.26 Turning Off the Indicator – B31.....	- 21 -
3.27 Setting a Log Interval – B34	- 22 -
3.28 Setting the SMS Time Zone – B35	- 22 -
3.29 Setting the GPRS Time Zone – B36	- 22 -
3.30 Checking the Engine First to Determine Tracker Running Status – B60	- 23 -
3.31 Setting SMS Event Characters – B91	- 23 -
3.32 Setting Event Authorization – B99	- 23 -
3.33 Output Control – C01.....	- 24 -
3.34 Setting a GPRS Event Transmission Mode – C03.....	- 25 -
3.35 SMS Display (LCD Display) – C11.....	- 25 -
3.36 Authorizing an RFID Card (MVT600/T1/T333/T3) – D10	- 25 -
3.37 Authorizing RFID Cards in Batches (MVT600/T1/T333/T3) – D11	- 26 -

3.38 Deleting an Authorized RFID (MVT600/T1/T333/T3) – D14	- 26 -
3.39 Deleting Authorized RFIDs in Batches (MVT600/T1/T333/T3) – D15	- 26 -
3.40 Reading the Tracker Firmware Version and SN – E91.....	- 26 -
3.41 Restarting the GSM Module – F01.....	- 27 -
3.42 Restarting the GPS Module – F02	- 27 -
3.43 Setting the Mileage and Run Time – F08	- 27 -
3.44 Deleting SMS/GPRS Cache Data – F09	- 28 -
3.45 Restoring Initial Settings – F11.....	- 28 -
3.46 Changing the Tracker Password – F20.....	- 28 -
3.47 Initializing the Tracker Password – FAB	- 28 -

1 Command Format

1.1 SMS Command Format

- SMS command sent from a mobile phone (SMS modem) to the tracker:

Password,<Command type>,<Command text>

Note: The password has four digits. The default password is 0000.

- SMS command sent from the tracker to a mobile phone (SMS modem):

1. Reply

IMEI, <Command type>,OK

2. Location report

SMS header,Date and time,Positioning status,GSM signal strength,Speed,Remaining battery capacity,Map link

SMS example:

Now,110721 16:40,V,12,56Km/h,97%,http://maps.meigps.com/?lat=22.513015&lng=114.057235

Descriptions about SMS data are as follows:

Parameter	Description	Example
SMS header	Indicates the SMS report type. For details, see section 1.2 "Event Code and SMS Header."	Now
Date and time	Format: YYMMDD hh:mm YY indicates year. MM indicates month. DD indicates date. hh indicates hour. mm indicates minute. Decimal	110721 16:40
Positioning status	Indicates the GPS signal status. A = Valid V = Invalid	A
GSM signal strength	Its value ranges from 0 to 31. Decimal GPRS data can be sent successfully only when the value is more than 16.	12
Speed	Unit: km/h Decimal	56
Remaining battery capacity	Indicates the remaining capacity of the built-in battery.	97%
Map link	Indicates the map link with a latitude and longitude. You can visit the website through a mobile phone. If you cannot visit HTTP websites through a mobile phone, enter the latitude and longitude in Google Maps (maps.google.com).	http://maps.meigps.com/?lat=22.513015&lng=114.057235 Latitude: 22.513015 Longitude: 114.057235

1.2 Event Code and SMS Header

OBD-related events are numbered from 129.

Event Code	Event	Default SMS Header (At Most 16 Bytes)
1	SOS Pressed	SOS
2	Input 2 Active	Ignition On: MVT100&MVT340&T322X Door Open: MVT380&MVT600&T1&MVT800&T333&T3 In2 Active: Other models
3	Input 3 Active	Ignition On: MVT600&T1&T333 &T3 Door Open: MVT800&T322X In3 Active: other models
4	Input 4 Active	Ignition On: MVT380&MVT800 In4 Active: other models
5	Input 5 Active	In5 Active
9	Input 1 Inactive	In1 Inactive
10	Input 2 Inactive	Ignition Off: MVT100&MVT340&T322X Door Close: MVT380&MVT600&T1&MVT800&T333&T3 In2 Inactive: other models
11	Input 3 Inactive	Ignition Off: MVT600&T1&T333&T3 Door Close: MVT800&T322X In3 Inactive: other models
12	Input 4 Inactive	Ignition Off: MVT380&MVT800 In4 Inactive: other models
13	Input 5 Inactive	In5 Inactive: other models
17	Low Battery	Low Battery
18	Low External Battery	Low Ext-Battery
19	Speeding	Speeding
20	Enter Geo-fence	Enter Fence N (N means the number of the fence)
21	Exit Geo-fence	Exit Fence N (N means the number of the fence)
22	External Battery On	Ext-Battery On Tracker connected: TC68S
23	External Battery Cut	Ext-Battery Cut Tracker removed: TC68S
24	Lose GPS Signal	Lose GPS Signal
25	GPS Signal Recovery	GPS Recovery
26	Enter Sleep	Enter Sleep
27	Exit Sleep	Exit Sleep
28	GPS Antenna Cut	GPS Antenna Cut
29	Device Reboot	Power On
31	Heartbeat	/
32	Heading Change	Heading Change
33	Distance Interval Tracking	Distance
34	Reply Current (Passive)	Now

35	Time Interval Tracking	Interval
36	Tow	Tow
37	RFID	(only for GPRS)
39	Picture	(only for GPRS)
41	Stop Moving	Stop moving
42	Start Moving	Start Moving
44	GSM Jammed	GSM Jammed
50	Temperature High	Temp High
51	Temperature Low	Temp Low
52	Fuel Filled	Fuel Full
53	Fuel Empty	Fuel Empty
56	Armed	Armed
57	Disarmed	Disarmed
58	Stealing	Stealing
63	GSM No Jamming	GSM No Jamming
65	Press Input 1 (SOS) to Call	/
66	Press Input 2 to Call	/
67	Press Input 3 to Call	/
68	Press Input 4 to Call	/
69	Press Input 5 to Call	/
70	Reject Incoming Call	/
71	Get Location by Call	/
72	Auto Answer Incoming Call	/
73	Listen-in (Voice Monitoring)	/
79	Fall	Fall
139	Maintenance Notice	Maintenance

Note: Data in the above figure is the default settings before delivery.

2 Command List

Command	Command Description	Applicable Model
A00	Real-Time Location Query	All
A02	Track by Time Interval (SMS)	All
A10	Real-Time Longitude and Latitude Query	All
A12	Track by Time Interval (GPRS)	All
A13	Setting the Direction Change Report Function	All
A14	Track by Distance	All
A15	Setting the Parking Scheduled Tracking	MVT100/340/380/600/T1/MVT800/T333/T3
A16	Enabling the Parking Scheduled Tracking	MVT100/340/380/600/T1/MVT800/T333/T3

A17	Enabling or Disabling the RFID Control OUT1	MVT600/T1/T333/T3
A19	3D-Shake Wake Up	MT90
A21	Setting GPRS Parameters	All
A22	Setting the DNS Server IP Address	All (excluding T322X/T355)
A23	Setting the Standby GPRS Server	All (excluding T322X)
A29	Setting a Man Down Alarm	MT90
A55	Setting Roaming and Track by Time Interval	All (excluding T322X/T355)
A70	Reading All Authorized Phone Numbers	All
A71	Setting a Combined Function Phone Number	All
A72	Setting a Listen-in Phone Number	All (excluding T322X/T355/MVT340)
A73	Setting the Smart Sleep Mode	All
A75	Querying the SIM Card Balance	T1/MVT600/MT90/MVT340/MVT380/MVT100/T333/T3
B05	Setting a Geo-Fence	All
B06	Deleting a Geo-Fence	All
B07	Setting the Speeding Alarm Function	All
B08	Setting the Towing Alarm Function	All (excluding T322X/T355)
B21	Setting the Anti-Theft Function	MVT100/340/380/600/T1/MVT800/T333/T322X/T3/T355/ T311
B31	Turning Off the Indicator	All (excluding T322X/T355)
B34	Setting a Log Interval	All (excluding MVT340/T322X/T355)
B35	Setting the SMS Time Zone	All
B36	Setting the GPRS Time Zone	All (excluding T355)
B60	Checking the Engine First to Determine Tracker Running Status	MVT100/380/600/T1/MVT800/T333/T3
B91	Setting SMS Event Characters	All (excluding T322X)
B99	Setting Event Authorization	All
C01	Output Control	MVT100/340/380/600/T1/MVT800/T333/T3
C03	Setting a GPRS Event Transmission Mode	All (excluding T322X/T355)
C11	SMS Display (LCD Display)	MVT600/T1/T333/T3
D10	Authorizing an RFID Card	MVT600/T1/T333/T3
D11	Authorizing RFID Cards in Batches	MVT600/T1/T333/T3
D14	Deleting an Authorized RFID	MVT600/T1/T333/T3
D15	Deleting Authorized RFIDs in Batches	MVT600/T1/T333/T3
E91	Reading the Tracker Firmware Version and SN	All

F01	Restarting the GSM Module	All (excluding T322X)
F02	Restarting the GPS Module	All (excluding T322X)
F08	Setting the Mileage and Run Time	All
F09	Deleting SMS/GPRS Cache Data	All
F11	Restoring Initial Settings	All
F20	Changing the Tracker Password	All
FAB	Initializing the Tracker Password	All

3 Command Details

3.1 Real-Time Location Query – A00

SMS Sending	0000,A00
SMS Reply	<i>Now,Date and time,Positioning status,GSM signal strength,Speed,Remaining battery capacity,Map link</i>
Description	Query the tracker location. For details, see section 1.2 "Event Code and SMS Header."
Applicable Model	All
Example	
SMS Sending	0000,A00
SMS Reply	Now,110721 16:40,V,12,56Km/h,97%,http://maps.meigps.com/?lat=22.513015&lng=114.057235

3.2 Track by Time Interval (SMS) – A02

SMS Sending	0000,A02, <i>Interval,Number of reporting times,Target phone number</i>
SMS Reply	IMEI,A02,OK
Description	When the interval is 0 , the scheduled SMS reporting function is disabled (default). When the interval is a value ranging from 1 to 65535, set an interval. The unit is minute. When the number of reporting times is 0, data has being reported (generally for platform positioning). When the number of reporting times is a value ranging from 1 to 255, set the number of reporting times. When the number of reporting times reaches the preset value, reporting stops. Target phone number: Data will be sent to the preset phone number at the specific time interval.
Applicable Model	All
Example	
SMS Sending	0000,A02,10,0
SMS Reply	353358017784062,A02,OK <i>After the above command is run successfully, the preset phone number will receive a</i>

	<p>positioning SMS every 10 minutes.</p> <p>Interval,110721</p> <p>16:40,V,12,56Km/h,97%,http://maps.meigps.com/?lat=22.513015&lng=114.057235</p>
--	---

3.3 Real-Time Longitude and Latitude Query – A10

SMS Sending	0000,A10
SMS Reply	IMEI,Now,<->Latitude,<->Longitude,Date and time, Positioning status,Number of satellites,GSM signal strength,Speed,Direction,Horizontal positioning accuracy,Altitude,Mileage,Run time,,I/O port status,,
Description	<p>Query the tracker location. The reply content is in longitude and latitude format. When A10 is used, if the tracker GPRS function is enabled and parameters are correct, the tracker will send a piece of GPRS location data which type is 34 to the server.</p> <p>The function is available for users who implement platform tracking using an SMS modem.</p>
Applicable Model	All
Example	
SMS Sending	0000,A10
SMS Reply	353358017784062,Now,22.535888,114.063034,080310161834,A,9,27,30,179,0,15,8890,1346,,00,,

3.4 Track by Time Interval (GPRS) – A12

SMS Sending	0000,A12,Interval
SMS Reply	IMEI,A12,OK
Description	<p>Set the GPRS tracking time interval.</p> <p>The interval is in unit of 10 seconds.</p> <p>When the interval is 0, the scheduled GPRS reporting function is disabled.</p> <p>The maximum time interval is 65535 x 10 seconds.</p> <p>Note: If data needs to be sent at a specific time interval after the vehicle starts or stops, the function needs to work with the A15 function. For details, see A15 and A16 commands.</p>
Applicable Model	All
Example	
SMS Sending	0000,A12,6
SMS Reply	353358017784062,A12,OK

3.5 Setting the Direction Change Report Function – A13

SMS Sending	0000,A13,Angle
SMS Reply	IMEI,A13,OK
Description	<p>When the driving angle exceeds the preset value, the tracker will send an SMS about the position to the authorized phone number.</p> <p>When the angle is 0, the direction change report function is disabled (default).</p>

	When the angle is a value ranging from 1 to 359, set the direction change angle. For the T322X, 15 is a recommended angle. For other trackers, 30 is recommended.
Applicable Model	All
Example	
SMS Sending	0000,A13,30
SMS Reply	353358017784062,A13,OK

3.6 Track by Distance – A14

SMS Sending	0000,A14, <i>Distance</i>
SMS Reply	IMEI,A14,OK
Description	When the driving distance is 0 , the distance tracking function is disabled (default). When the driving distance is a value ranging from 1 to 4294967295, set the distance. The unit is meter. Note: If the GPRS scheduled tracking and distance tracking functions are both set, reporting complies with the "first reach first report" rule and the interval and distance of next report are re-calculated.
Applicable Model	All
Example	
SMS Sending	0000,A14,1000
SMS Reply	353358017784062,A14,OK <i>After the above command is run successfully, if the driving distance reaches 1000m, the tracker will send a data packet to the preset authorized phone number.</i> Distance,110721 16:40,V,12,56Km/h,97%,http://maps.meigps.com/?lat=22.513015&lng=114.057235

3.7 Setting the Parking Scheduled Tracking Function – A15

SMS Sending	0000,A15, <i>Interval</i>
SMS Reply	IMEI,A15,OK
Description	The function applies for vehicle trackers. With the function, the number of GPRS messages is reduced, and thus GPRS traffic is saved. After the A15 function is set, the A16 function is automatically enabled. For details about engine status, see section 3.8 "Enabling the Parking Scheduled Tracking Function – A16." The interval is in unit of 10 seconds. When the interval is 0 , the GPRS scheduled reporting function is disabled. The maximum interval is 65535 x 10 seconds.
Applicable Model	MVT100/MVT340/MVT380/MVT600/T1/MVT800/T322X/T333/T3
Example	
SMS Sending	0000,A15,6
SMS Reply	353358017784062,A15,OK

3.8 Enabling the Parking Scheduled Tracking Function – A16

SMS Sending	0000,A16,Status																
SMS Reply	IMEI,A16,OK																
Description	<p>Related input ports (high level) of vehicle trackers must connect to engine status detection. Otherwise, the function is unavailable. The first positive input ports of vehicle trackers are as follows:</p> <table border="1"> <thead> <tr> <th>Vehicle Tracker</th> <th>First Positive Input Port</th> </tr> </thead> <tbody> <tr> <td>MVT100</td> <td>Input port 2</td> </tr> <tr> <td>MVT340</td> <td>Input port 2</td> </tr> <tr> <td>MVT380</td> <td>Input port 4</td> </tr> <tr> <td>MVT600</td> <td>Input port 3</td> </tr> <tr> <td>T1/T333/T3</td> <td>Input port 3</td> </tr> <tr> <td>MVT800</td> <td>Input port 4</td> </tr> <tr> <td>T322X</td> <td>Input port 2</td> </tr> </tbody> </table> <p>When the activation status is 1, the parking scheduled tracking function is enabled, and GPRS data is sent at the following interval:</p> <ul style="list-style-type: none"> ● Interval of the A12 function when the engine is on ● Interval of the A15 function when the engine is off <p>When the activation status is 0, the parking scheduled tracking function is disabled, and GPRS data is sent at the following interval:</p> <ul style="list-style-type: none"> ● Interval of the A12 function when the engine is on ● Interval of the A12 function when the engine is off <p>Note: The TC68S can determine whether the engine is activated based on vehicle voltage.</p>	Vehicle Tracker	First Positive Input Port	MVT100	Input port 2	MVT340	Input port 2	MVT380	Input port 4	MVT600	Input port 3	T1/T333/T3	Input port 3	MVT800	Input port 4	T322X	Input port 2
Vehicle Tracker	First Positive Input Port																
MVT100	Input port 2																
MVT340	Input port 2																
MVT380	Input port 4																
MVT600	Input port 3																
T1/T333/T3	Input port 3																
MVT800	Input port 4																
T322X	Input port 2																
Applicable Model	MVT100/MVT340/MVT380/MVT600/T1/MVT800/TC68S/T322X/T333/T3																
Example																	
SMS Sending	0000,A16,0																
SMS Reply	353358017784062,A16,OK																

3.9 Enabling or Disabling the RFID Control OUT1 Function (MVT600/T1/T333/T3) – A17

SMS Sending	0000,A17,X
SMS Reply	IMEI,A17,OK
Description	<p>When <i>X</i> is 1, the RFID control OUT1 function is enabled. Ensure that the engine must connect to input 3 and the RFID has been authorized.</p> <p>When <i>X</i> is 0, the RFID control OUT1 function is disabled (default).</p> <p>For example, after swiping the authorized RFID card, you must start the engine within one minute. If the time expires, you need to swipe the card again to start the engine. After that, input 3 has been detecting engine status. When input 3 detects that the engine status is ACC ON, the engine is not activated. When input 3 detects that the engine is stopped before one minute, swipe the card to start the engine.</p>

	Note: If the function is enabled, OUTPUT1 is activated. For details about how to authorize a RFID, see commands D10–D15.
Applicable Model	MVT600/T1/T333/T3
Example	
SMS Sending	0000,A17,0
SMS Reply	353358017784062,A17,OK

3.10 3D-Shake Wake Up (MT90) – A19

SMS Sending	0000,A19,X
SMS Reply	IMEI,A19,OK
Description	When wakeup is not required in the sleep mode, X is set to 0. When vibration and wakeup are required in the deep sleep mode, X is set to 1.
Applicable Model	MT90
Example	
SMS Sending	0000,A19,0
SMS Reply	353358017784062,A19,OK

3.11 Setting GPRS Parameters – A21

SMS Sending	0000,A21, <i>Connection mode,IP address,Port,APN,APN user name,APN password</i>
SMS Reply	IMEI,A21,OK
Description	When the connection mode is 0 , the GPRS function is disabled. When the connection mode is 1 , the GPRS function is enabled, and the TCP/IP reporting mode is used. When the connection mode is 2 , the GPRS function is enabled, and the UDP reporting mode is used. IP address: IP address or domain name. A maximum of 32 bytes are supported. Port: a maximum of 5 digits APN/APN user name/APN password: a maximum of 32 bytes respectively If no user name and password are required, leave them blank.
Applicable Model	All
Example	
SMS Sending	0000,A21,1,67.203.13.26,8800,APN,APN username,APN password
SMS Reply	353358017784062,A21,OK

3.12 Setting the DNS Server IP Address – A22

SMS Sending	0000,A22, <i>DNS server IP address</i>
SMS Reply	IMEI,A22,OK
Description	An incorrect DNS server IP address may lead to GPRS data reporting failures after the A21 command is used. Use the A22 command to set the DNS server IP address (confirm

	the IP address with your domain name provider.). Then use the A21 command to reset the domain name. DNS server IP address: a maximum of 16 bytes
Applicable Model	Excluding T322X/T355
Example	
SMS Sending	0000,A22,202.105.21.232
SMS Reply	353358017784062,A22,OK <i>The command is used to set the Oray DNS server IP address.</i>

3.13 Setting the Standby GPRS Server – A23

SMS Sending	0000,A23,IP address,Port
SMS Reply	IMEI,A23,OK
Description	IP address: a maximum of 32 bytes Port: a maximum of 5 digits When the tracker fails to send data to the active server set by command A21, data is automatically sent to the standby server. This avoids data losses.
Applicable Model	Excluding T322X
Example	
SMS Sending	0000,A23,67.203.13.26,8800
SMS Reply	353358017784062,A23,OK

3.14 Setting a Man Down Alarm – A29

SMS Sending	0000,A29,Switch,Time,Grade,Wait time
SMS Reply	IMEI,A29,OK
Description	<ol style="list-style-type: none"> 1. Switch: indicates the man down alarm detection switch. Value range: 0–1. When the parameter value is 1, the man down alarm function is enabled. When the parameter value is 0, the man down alarm function is disabled. The default value is 0. 2. Time: indicates the buzzing and vibration duration after falling. In this period, you can press any button to clear the alarm, and thus avoid inaccurate alarm information. After the period, an alarm will be generated or a call will be made. The parameter unit is second. Value range: 0–255. Default value: 10. 3. Grade: indicates the man down alarm grade. Its value ranges from 0 to 3 and it is in decimal format. The default value is 1. The smaller the value is, the high probability an alarm is generated. 4. Wait time: indicates the still duration after falling. The parameter unit is second. Value range: 0–65535. The default value is 0. If the still duration after falling exceeds the preset value, a Man Down alarm will be generated.
Applicable Model	MT90
Example	
SMS Sending	0000,A29,1,10,1,0
SMS Reply	353358017784062,A29,OK

3.15 Setting Roaming and Track by Time Interval – A55

SMS Sending	0000,A55,Scheduled mode,T1,T2,T3,T4																								
SMS Reply	IMEI,A55, <Scheduled mode,T1,[T2],[T3],[T4]>																								
Description	<ol style="list-style-type: none"> Scheduled mode: decimal. Its value is the combinations of ACC ON, ACC OFF, Local, and Roaming. <ul style="list-style-type: none"> T1: indicates the data uploading interval which is not restricted by ACC ON and roaming. The functions are the same as that of A12. T2: indicates the data uploading interval when ACC OFF or ACC OFF in Local mode. T3: indicates the data uploading interval when ACC ON in Roaming mode, or the interval which is not restricted by roaming when ACC OFF. T4: indicates the data uploading interval when ACC OFF in Roaming mode. The following combined scheduled modes are supported: <ul style="list-style-type: none"> Mode 0 (T1): The functions are the same as that of A12. All data will be uploaded at the T1 interval. The command format is A55,0,T1. Other parameters such as T2 and T3 will be invalid. Mode 1 (T1 + T2): The functions are the same as that of A12 and A15. Parameter T1 is the data uploading interval when ACC ON. Parameter T2 is the data uploading interval when ACC OFF. The command format is A55,1,T1,T2. Mode 2 (T1 + T3): In Local mode, parameter T1 is the data uploading interval. In roaming mode, parameter T3 is the data uploading interval. The command format is A55,2,T1,T3. Mode 3 (T1 + T3 + T4): In Local mode, parameter T1 is the data uploading interval and the interval is not restricted by the engine status. In roaming mode, when the engine starts, parameter T3 is the data uploading interval; when the engine stops, parameter T4 is the data uploading interval. The command format is A55,3,T1,T3,T4. Mode 4 (T1 + T2 + T3 + T4): In Local mode, when the engine starts, parameter T1 is the data uploading interval; when the engine stops, parameter T2 is the data uploading interval. In Roaming mode, when the engine starts, parameter T3 is the data uploading interval; when the engine stops, parameter T4 is the data uploading interval. After a GPRS interval is set by using the A55 command, the tracker will reply the interval parameters. If only 0000,A55 is sent, read tracker GPRS interval parameters. 																								
Applicable Model	<table border="1"> <thead> <tr> <th>Tracker</th> <th>Mode 0</th> <th>Mode 1</th> <th>Mode 2</th> <th>Mode 3</th> <th>Mode 4</th> </tr> </thead> <tbody> <tr> <td>T1/T333/T3</td> <td>√</td> <td>√</td> <td>√</td> <td>√</td> <td>√</td> </tr> <tr> <td>MVT600</td> <td>√</td> <td>√</td> <td>√</td> <td>√</td> <td>√</td> </tr> <tr> <td>MVT800</td> <td>√</td> <td>√</td> <td>√</td> <td>√</td> <td>√</td> </tr> </tbody> </table>	Tracker	Mode 0	Mode 1	Mode 2	Mode 3	Mode 4	T1/T333/T3	√	√	√	√	√	MVT600	√	√	√	√	√	MVT800	√	√	√	√	√
Tracker	Mode 0	Mode 1	Mode 2	Mode 3	Mode 4																				
T1/T333/T3	√	√	√	√	√																				
MVT600	√	√	√	√	√																				
MVT800	√	√	√	√	√																				

	MVT380	√	√	√	√	√
	MVT100	√	√	√	√	√
	MT90	√		√		
	TC68S	√		√		
	T355	√	√	√	√	√
Example						
SMS Sending	0000,A55,0.6					
SMS Reply	353358017784062,A55,0,6					

3.16 Reading All Authorized Phone Numbers – A70

SMS Sending	0000,A70
SMS Reply	<i>IMEI,A70,SOS phone number 1,SOS phone number 2,SOS phone number 3,Listen-in phone number 1,Listen-in phone number 2</i>
Description	Read all authorized phone numbers.
Applicable Model	All
Example	
SMS Sending	0000,A70
SMS Reply	353358017784062,A70,13811111111,13822222222,13833333333,13844444444,1385555555

3.17 Setting a Combined Function Phone Number – A71

SMS Sending	0000,A71, <i>Phone number 1,Phone number 2,Phone number 3</i>
SMS Reply	IMEI,A71,OK
Description	<p>Phone number: A phone number has a maximum of 16 bytes. If no phone numbers are set, leave them blank. Phone numbers are empty by default.</p> <p>Phone number 1/2/3: Set the phone number to the SOS phone number. When you call the tracker by using the phone number, the tracker will reply an SMS with the location and send geo-fence alarms and low power alarms.</p> <p>When the SOS button is pressed, the tracker will dial phone numbers 1, 2, and 3 in sequence. The tracker stops dialing when a phone number responds.</p> <p>Note: If no phone numbers are set and commas are remained, phone numbers set before will be deleted. In addition, alarm events will be overlapped.</p> <p>If all combined function phone numbers need to be deleted, send 0000,A71.</p>
Applicable Model	All
Example	
SMS Sending	0000,A71,13811111111,13822222222,13833333333
SMS Reply	353358017784062,A71,OK

3.18 Setting a Listen-in Phone Number – A72

SMS Sending	0000,A72,Listen-in phone number 1,Listen-in phone number 2
SMS Reply	IMEI,A72,OK
Description	<p>When you call the tracker by using the authorized listen-in phone number, the tracker will answer the call automatically and enter the listen-in state. In this way, the tracker will not make any sound.</p> <p>A maximum of two phone numbers can be set. Each phone number has a maximum of 16 digits. If no phone numbers are set, leave them blank. Phone numbers are empty by default.</p> <p>If no phone numbers are set and commas are remained, phone numbers set before will be deleted.</p> <p>If all phone numbers need to be deleted, send 0000,A72.</p>
Applicable Model	Excluding T322X/T355/MVT340
Example	
SMS Sending	0000,A72,138444444444,13855555555
SMS Reply	353358017784062,A72,OK

3.19 Setting the Smart Sleep Mode – A73

SMS Sending	0000,A73,Sleep level
SMS Reply	IMEI,A73,OK
Description	<p>Set the automatic smart sleep mode when the tracker is idle.</p> <p>When the sleep level is 0, the sleep mode is disabled (default).</p> <p>When the sleep level is 1, the tracker enters the normal sleep mode. The GSM module always works, and the GPS module occasionally enters the sleep mode. The tracker works 25% longer in the normal sleep mode than that in the normal working mode. The mode is not recommended for users who set the scheduled tracking at a short interval. In this way, the mode will affect trace integrity.</p> <p>When the sleep level is 2, the tracker enters the deep sleep mode. If the tracker is not activated after five minutes, the GPS module is stopped, and the GSM module enters the sleep mode. If the tracker is activated, the GPS and GSM modules are waken up. A heartbeat event occurs only in the deep sleep mode. A heartbeat event is uploaded every one hour by default.</p> <p>Activation actions include: SOS alarm, low internal/external battery, external power status, GPS antenna cutoff alarm, towing alarm, high temperature, low temperature, fuel stealing, vehicle stealing, ACC ON, (button) changes on any input port, vibration, incoming call, SMS receiving, call, and heartbeat event (The GPS is disabled during heartbeat wakeup.).</p> <p>Note:</p> <ul style="list-style-type: none"> ● The T355 is in deep sleep mode by default. If the tracker is inactive (drop/incoming call/SMS/vibration) for 5 minutes, the tracker enters deep sleep mode. In this way, a triggering event (drop/incoming call/SMS/vibration) can

	<p>wake the device up, and then the device enters working mode. In deep sleep mode, if there is no triggering event (drop/incoming call/SMS/vibration) within 25 minutes, the device will automatically enter super power-saving mode. In this mode, only a drop or vibration event can wake the device up. GPS and GSM modules can be enabled intelligently based on vehicle driving status, which saves power.</p> <ul style="list-style-type: none"> ● The MT90 can enter sleep mode under vibration, and vibration cannot wake the MT90 up from sleep mode. However, you can use the A19 command to wake up the MT90. By default, you cannot wake the MT90 up by vibration. ● After the T322X stops working for 15 minutes, it automatically enters the power-saving sleep mode. In this way, the GPS module does not work, and the T322X does not upload tracking data at a regular interval. Instead, the T322X sends heartbeat data packets about the positioning cease (GPS invalid) to the platform every 60 minutes. The interval for sending heartbeat packets can be changed. If the T322X vibrates, the T322X will be woken up, continue to work normally, and report data including heartbeat packets at a regular interval. ● In any condition, you can use an SMS or a GPRS command to disable the sleep mode, and then the tracker exits the sleep mode and returns back to the normal working mode.
Applicable Model	All
Example	
SMS Sending	0000,A73,2
SMS Reply	353358017784062,A73,OK

3.20 Querying the SIM Card Balance – A75

SMS Sending	0000,A75, <Ussd code>/<Type,Code/Num,Content>
SMS Reply	IMEI,A75, <content>
Description	<ol style="list-style-type: none"> 1. Support USSD commands, calling (not allow voice menus), and SMS. 2. Parameters will not be saved. Query commands: <ul style="list-style-type: none"> ● Type: indicates the service type (USSD, call, and SMS). The letters can be detected when they are uppercase. ● Code: indicates the USSD command code for balance query. ● Num: indicates the telephone number. ● Content: indicates the text for SMS query. ● Ussd code: indicates the USSD code text for balance query. <p>e.g.</p> <p>A75,*120#<Send a command for USSD balance query. Forward to the preset phone number.></p> <p>A75,ussd,*120#<Send a command for USSD balance query. Forward to the preset phone number.></p> <p>A75,call,1008611<Call to query the balance. Forward an SMS to the preset phone number or platform.></p>

	<p>A75,call,10010111<Call to query the balance. Forward an SMS to the preset phone number or platform.></p> <p>A75,sms,10010,cxye<Send an SMS to query. Parse the long SMS by PDU UCS2. Forward the SMS to the platform or the preset phone number.></p> <p>3. The query results will be sent to the phone number or platform by PDU UCS2. Long SMSs need to be supported.</p>
Applicable Model	T1/MVT600/MT90/MVT340/MVT380/MVT100/T333/T3
Example	
SMS Sending	0000, A75, *120#
SMS Reply	A75,Saldo 37,71kr. Kortet giltigt till 2014-07-03. Basprislista 1,99kr/min till alla och sms 0,99 kr/st. Ladda f r att ringa billigare, se telia.se/refill.

3.21 Setting a Geo-Fence – B05

SMS Sending	0000,B05,Geo-fence number,Latitude,Longitude,Radius,In geo-fence alarm,Out geo-fence alarm
SMS Reply	IMEI,B05,OK
Description	<p>Geo-fence number: 1–8. A maximum of eight geo-fences can be set.</p> <p>Latitude: latitude of the geo-fence center; decimal; accurate to 6 digits after the decimal part. If there are only 4 characters in the decimal part, add two digits 0. Otherwise, the command cannot be used successfully.</p> <p>Longitude: longitude of the geo-fence center; decimal; accurate to 6 digits after the decimal part. If there are only 4 characters in the decimal part, add two digits 0. Otherwise, the command cannot be used successfully.</p> <p>Radius: The value ranges from 1 to 4294967295. The unit is meter.</p> <p>When the In Geo-fence alarm is 0, the alarm function is disabled.</p> <p>When the In Geo-fence alarm is 1, the alarm function is enabled.</p> <p>When the Out Geo-fence alarm is 0, the alarm function is disabled.</p> <p>When the Out Geo-fence alarm is 1, the alarm function is enabled.</p>
Applicable Model	All
Example	
SMS Sending	0000,B05,1,22.913191,114.079882,1000,0,1
SMS Reply	<p>353358017784062,B05,OK</p> <p><i>When the tracker exits the geo-fence (latitude: 22.913191; longitude: 114.079882; radius: 1000m), the tracker will send the following alarm information to the preset authorized phone number:</i></p> <p><i>Exit GEO ,110721</i></p> <p><i>16:40,V,12,56Km/h,97%,http://maps.meigps.com/?lat=22.513015&lng=114.057235</i></p>

3.22 Deleting a Geo-Fence – B06

SMS Sending	0000,B06,Geo-fence number
SMS Reply	IMEI,B06,OK

Description	Geo-fence number: 1–8. Only one geo-fence can be deleted each time by SMS or GPRS command.
Applicable Model	All
Example	
SMS Sending	0000,B06,1
SMS Reply	353358017784062,B06,OK

3.23 Setting the Speeding Alarm Function – B07

SMS Sending	0000,B07, <i>Alarm speed</i>
SMS Reply	IMEI,B07,OK
Description	When the alarm speed is 0 , the speeding alarm function is disabled (default). When the alarm speed is a value ranging from 1 to 255, set the speed limit. When the driving speed reaches the value, a speeding alarm will be generated.
Applicable Model	All
Example	
SMS Sending	0000,B07,60
SMS Reply	353358017784062,B07,OK <i>When the tracker driving speed reaches 60 km/h, the tracker will send the following alarm information to the preset authorized phone number:</i> <i>Speeding,110721</i> <i>16:40,V,12,61Km/h,97%,http://maps.meigps.com/?lat=22.513015&lng=114.057235</i>

3.24 Setting the Towing Alarm Function – B08

SMS Sending	0000,B08, <i>Vibration duration</i>
SMS Reply	IMEI,B08,OK
Description	When the tracker's vibration duration exceeds the preset value, the tracker will send an alarm to an authorized phone number or the server. Before using the towing alarm function, ensure that the smart sleep level is set to 2 by using the A73 command and the consecutive vibration duration is set by using the B08 command. Otherwise, the towing alarm function is unavailable. When the consecutive vibration duration is 0 , the towing alarm function is disabled (default). When the consecutive vibration duration is a value ranging from 1 to 255, set the waiting time of an alarm caused by consecutive vibration. The unit is second.
Applicable Model	Excluding T311/T355
Example	
SMS Sending	0000,B08,3
SMS Reply	353358017784062,B08,OK <i>When the tracker vibrates for more than consecutive three seconds, the tracker will send</i>

	<p>the following alarm information to the preset authorized phone number:</p> <p>Tow,110721</p> <p>16:40,V,12,56Km/h,97%,http://maps.meigps.com/?lat=22.513015&lng=114.057235</p>
--	---

3.25 Setting the Anti-Theft Function – B21

SMS Sending	0000,B21,Status																								
SMS Reply	IMEI,B21,OK																								
Description	<p>When the activation status is 1 (default value), the anti-theft function is enabled. An alarm is generated when the first negative input and first positive input of vehicle trackers excluding SOS are activated. For example, an alarm is generated when input 3 or 4 of the MVT800 is activated or input 2 or 3 of the T322X is activated.</p> <p>When the activation status is 0, the anti-theft function is disabled. No alarm is generated when the first negative input and first positive input of vehicle trackers excluding SOS are activated. Recorded data can only be read by GPSLog or Meitrack Manager software.</p> <p>Note: The function is only available for MVT series, T1, and T322X vehicle trackers. The following lists inputs of trackers:</p> <table border="1"> <thead> <tr> <th>Tracker</th> <th>Negative Input (Vehicle Door)</th> <th>Positive Input (ACC)</th> </tr> </thead> <tbody> <tr> <td>MVT100</td> <td>-</td> <td>Input 2</td> </tr> <tr> <td>MVT340</td> <td>-</td> <td>Input 2</td> </tr> <tr> <td>MVT380</td> <td>Input 2</td> <td>Input 4</td> </tr> <tr> <td>MVT600</td> <td>Input 2</td> <td>Input 3</td> </tr> <tr> <td>T1/T333/T3</td> <td>Input 2</td> <td>Input 3</td> </tr> <tr> <td>MVT800</td> <td>Input 3</td> <td>Input 4</td> </tr> <tr> <td>T322X</td> <td>Input 3</td> <td>Input 2</td> </tr> </tbody> </table> <p>Note: When the T322X/MVT800 is in arming state and input 3 is triggered, a vehicle stealing alarm will be generated, the buzzer makes a sound, and the tracker makes a call and sends an SMS to the authorized phone number. In this way, if T322X input 2/MVT800 input 4 is triggered, output 1 is activated and the tracker makes a call and sends an SMS to the authorized phone number.</p>	Tracker	Negative Input (Vehicle Door)	Positive Input (ACC)	MVT100	-	Input 2	MVT340	-	Input 2	MVT380	Input 2	Input 4	MVT600	Input 2	Input 3	T1/T333/T3	Input 2	Input 3	MVT800	Input 3	Input 4	T322X	Input 3	Input 2
Tracker	Negative Input (Vehicle Door)	Positive Input (ACC)																							
MVT100	-	Input 2																							
MVT340	-	Input 2																							
MVT380	Input 2	Input 4																							
MVT600	Input 2	Input 3																							
T1/T333/T3	Input 2	Input 3																							
MVT800	Input 3	Input 4																							
T322X	Input 3	Input 2																							
Applicable Model	MVT100/MVT340/MVT380/MVT600/T1/MVT800/T322X/T333/T3																								
Example																									
SMS Sending	0000,B21,1																								
SMS Reply	353358017784062,B21,OK																								

3.26 Turning Off the Indicator – B31

SMS Sending	0000,B31,A
SMS Reply	IMEI,B31,OK
Description	When A is 00 , the tracker's indicator is turned on (default). You can query the device's running status according to the indicator status.

	When A is 10 , the tracker's indicator is turned off.
Applicable Model	Excluding T322X/T355
Example	
SMS Sending	0000,B31,10
SMS Reply	353358017784062,B31,OK

3.27 Setting a Log Interval – B34

SMS Sending	0000,B34, <i>Log interval</i>
SMS Reply	IMEI,B34,OK
Description	Set the interval for recording data to the tracker flash memory when the GPS is valid. When the log interval is 0 , the recorder function is disabled (default). When the log interval is a value ranging from 1 to 65535, set the interval. The unit is second.
Applicable Model	Excluding T322X/MVT340/T355
Example	
SMS Sending	0000,B34,60
SMS Reply	353358017784062,B34,OK

3.28 Setting the SMS Time Zone – B35

SMS Sending	0000,B35, <i>SMS minute</i>
SMS Reply	B35,OK
Description	The default time zone of the tracker is GMT 0. You can run the B35 command to change the SMS report time zone to the local time zone. The SMS report time zone is different from the GPRS data packet time zone. When SMS minute is 0 , the time zone is GMT 0 . When SMS minute is a value ranging from -720 to 780, set time zones.
Applicable Model	All
Example	
SMS Sending	0000,B35,480
SMS Reply	353358017784062,B35,OK

3.29 Setting the GPRS Time Zone – B36

SMS Sending	0000,B36, <i>GPRS minute</i>
SMS Reply	IMEI,B36,OK
Description	When GPRS minute is 0 , the time zone is GMT 0 (default). The MS02 can automatically detect the user time zone, so that the GPRS time zone does not need to be changed. Otherwise, inaccurate data occurs. When GPRS minute is a value ranging from -720 to 780, set time zones.
Applicable Model	Excluding T355

Example	
SMS Sending	0000,B36,480
SMS Reply	353358017784062,B36,OK

3.30 Checking the Engine First to Determine Tracker Running Status – B60

SMS Sending	0000,B60,X
SMS Reply	IMEI,B60,OK
Description	<p>When X is 1, check the engine first to determine whether the tracker is moving or stops. This prevents static drift.</p> <p>When X is 0, you do not need to check the engine to determine whether the tracker is moving or stops.</p> <p>The first positive input of the tracker connects to engine detection by default.</p>
Applicable Model	MVT100/MVT380/MVT600/T1/MVT800/T322X/T333/T3
Example	
SMS Sending	0000,B60,1
SMS Reply	353358017784062,B60,OK

3.31 Setting SMS Event Characters – B91

SMS Sending	0000,B91, <i>Event SMS code</i> , <i>SMS header</i>
SMS Reply	IMEI,B91,OK
Description	<p>Header: a maximum of 16 bytes</p> <p>For details, see section 1.2 "Event Code and SMS Header."</p>
Applicable Model	Excluding T322X
Example	
SMS Sending	0000,B91,1,SOS
SMS Reply	353358017784062,B91,OK

3.32 Setting Event Authorization – B99

SMS Sending	<p>0000, B99,<SMS>/<0>,<Phone number location>/<Authorized phone number>,<Operation code>, [Event code 1].....[Event code n]</p> <p>0000,B99,<CALL>/<1>,<Phone number location>/<Authorized phone number>,<Operation code>, [Event code 1].....[Event code n]</p> <p>0000,B99,<GPRS>/<2>,<Operation code>, [Event code 1].....[Event code n]</p> <p>0000,B99,<CAMERA>/<3>,<Operation code>, [Event code 1].....[Event code n]</p> <p>0000,B99,<BUZZER>/<4>,<Operation code>, [Event code 1].....[Event code n].</p>
SMS Reply	<p>IMEI,B99,<SMS>/<0>,<Phone number location>,<Authorized phone number>, [Event code 1].....[Event code n]</p> <p>IMEI,B99,<CALL>/<1>,<Phone number location>,<Authorized phone number>, [Event code 1].....[Event code n]</p>

	IMEI,B99,<GPRS>/<2>,[Event code 1].....[Event code n] IMEI,B99,<CAMERA>/<3>,[Event code 1].....[Event code n] IMEI,B99,<BUZZER>/<4>,[Event code 1].....[Event code n]
Description	Fields SMS, CALL, CAMEA, GPRS, BUZZER can be presented by 0–4 in decimal string. Operation codes GET, SET, ADD, and DEL can be presented by 0–3 in decimal string. These characters are not case-sensitive. Note: Ensure that an authorized phone number is set by using the A71 command or the parameter configuration tool before the B99 command is used to set the SMS/CALL event code. The tracker compares the authorized phone number issued by B99 with the authorized phone number (excluding +86 characters) of the tracker. If the phone numbers are the same, the new event code will be stored. If the phone numbers are inconsistent, an error SMS will be sent.
Applicable Model	All
Example	
SMS Sending	0000, B99,gprs,get
SMS Reply	353358017784062, B99,1,17,18

3.33 Output Control – C01

SMS Sending	0000,C01,Speed,ABCDE
SMS Reply	IMEI,C01,OK
Description	When the speed is 0 , no speed limit exists. That is, when the tracker receives a command, the output control takes effect immediately. When the speed is a value ranging from 1 to 255 (unit: km/h), set the speed limit for output control. When the driving speed is lower than the speed limit, the output control takes effect. A=0, close output (OUT1) - open drain A=1, open output (OUT1) - connect to GND A=2, remain previous status. B=0, close output (OUT2) - open drain B=1, open output (OUT2) - connect to GND B=2, remain previous status. C=0, close output (OUT3) - open drain C=1, open output (OUT3) - connect to GND C=2, remain previous status. D=0, close output (OUT4) - open drain D=1, open output (OUT4) - connect to GND D=2, remain previous status. E=0, close output (OUT5) - open drain E=1, open output (OUT5) - connect to GND E=2, remain previous status.
Applicable Model	MVT100/MVT340/MVT380/MVT600/T1/MVT800/T333/T3
Example	

SMS Sending	0000,C01,20,12221
SMS Reply	353358017784062,C01,OK

3.34 Setting a GPRS Event Transmission Mode – C03

SMS Sending	0000,C03,X
SMS Reply	IMEI,C03,OK
Description	X = 0: automatic event report (default) X = 1: Before another event can be transmitted, existing event reports need to be confirmed and deleted on the server by the AFF command. Select this mode when GPRS uses UDP.
Applicable Model	Excluding T322X
Example	
SMS Sending	0000,C03,0
SMS Reply	353358017784062,C03,OK

3.35 SMS Display (LCD Display) – C11

SMS Sending	0000,C11, <i>Text</i>
SMS Reply	IMEI,C11,OK
Description	The command is used to show an SMS send by a mobile phone on the LCD display. Text: indicates the SMS text. ASCII character string; a maximum of 140 bytes. The MVT600 does not support Unicode.
Applicable Model	MVT600/T1/T333/T3
Example	
SMS Sending	0000,C11,SMS Message
SMS Reply	353358017784062,C11,OK

3.36 Authorizing an RFID Card (MVT600/T1/T333/T3) – D10

SMS Sending	0000,D10,RFID(1),RFID(2),...,RFID(n)
SMS Reply	IMEI,D10, OK
Description	RFID (n): indicates the authorized RFID card number. The value ranges from 1 to 4294967295. Decimal. A maximum of 50 RFID cards can be authorized one time.
Applicable Model	MVT600/T1/T333/T3
Example	
SMS Sending	0000,D10,00000001
SMS Reply	353358017784062,D10,OK

3.37 Authorizing RFID Cards in Batches (MVT600/T1/T333/T3) – D11

SMS Sending	0000,D11,RFID card start number,n
SMS Reply	IMEI,D11, OK
Description	RFID card start number: The value ranges from 1 to 4294967295. Decimal. n: indicates the number of batch-authorized RFID cards. Decimal. The maximum value is 128 .
Applicable Model	MVT600/T1/T333
Example	
SMS Sending	0000,D11,00000001,128
SMS Reply	353358017784062,D11,OK

3.38 Deleting an Authorized RFID (MVT600/T1/T333/T3) – D14

SMS Sending	D14,RFID(1),RFID(2),...,RFID(n)
SMS Reply	D14, OK
Description	RFID (n): indicates the RFID to be deleted. The value ranges from 1 to 4294967295. Decimal. A maximum of 50 RFID cards can be deleted one time. One SMS (including protocols) cannot exceed 140 bytes.
Applicable Model	MVT600/T1/T333/T3
Example	
SMS Sending	0000,D14,00000001
SMS Reply	353358017784062,D14,OK

3.39 Deleting Authorized RFIDs in Batches (MVT600/T1/T333/T3) – D15

SMS Sending	0000,D15,RFID card start number,n
SMS Reply	IMEI,D15, OK
Description	RFID card start number: ranges from 1 to 4294967295. Decimal. n: indicates the number of RFID cards to be deleted in batches. Decimal. The maximum value is 128 . When the card start number is a value ranging from 1 to 4294967295 and n is greater than or equal to 65536, all authorized numbers will be deleted.
Applicable Model	MVT600/T1/T333/T3
Example	
SMS Sending	0000,D15,00000001,128
SMS Reply	353358017784062,D15,OK

3.40 Reading the Tracker Firmware Version and SN – E91

SMS Sending	0000,E91
-------------	----------

SMS Reply	IMEI,E91,Version,SN
Description	Read the tracker's firmware version and SN.
Applicable Model	All
Example	
SMS Sending	0000,E91
SMS Reply	353358017784062,E91,FWV1.00,12345678

3.41 Restarting the GSM Module – F01

SMS Sending	0000,F01
SMS Reply	IMEI,F01,OK
Description	Restart the GSM module.
Applicable Model	Excluding T322X
Example	
SMS Sending	0000,F01
SMS Reply	353358017784062,F01,OK

3.42 Restarting the GPS Module – F02

SMS Sending	0000,F02
SMS Reply	IMEI,F02,OK
Description	Restart the GPS module.
Applicable Model	Excluding T322X
Example	
SMS Sending	0000,F02
SMS Reply	353358017784062,F02,OK

3.43 Setting the Mileage and Run Time – F08

SMS Sending	0000,F08,Run time,Mileage
SMS Reply	IMEI,F08,OK
Description	<p>Run time:</p> <ul style="list-style-type: none"> ● Value range: [0, 4294967295] ● Decimal ● Unit: second <p>If the parameter leaves blank, it will not be set.</p> <p>Mileage:</p> <ul style="list-style-type: none"> ● Value range: [0, 4294967295] ● Decimal ● Unit: meter <p>If the parameter is left blank, it will not be set.</p>
Applicable Model	All

Example	
SMS Sending	0000,F08,0,4825000
SMS Reply	353358017784062,F08,OK <i>Note: In the command above, the run time is 0, and the mileage is 4825 km.</i>

3.44 Deleting SMS/GPRS Cache Data – F09

SMS Sending	0000,F09, <i>Number</i>
SMS Reply	IMEI,F09,OK
Description	If the number is 1 , delete all SMS cache data to be sent. If the number is 2 , delete all GPRS cache data to be sent. If the number is 3 , delete all SMS and GPRS cache data to be sent.
Applicable Model	All
Example	
SMS Sending	0000,F09,1
SMS Reply	353358017784062,F09,OK

3.45 Restoring Initial Settings – F11

SMS Sending	0000,F11
SMS Reply	IMEI,F11,OK
Description	Restore initial settings except the SMS password.
Applicable Model	All
Example	
SMS Sending	0000,F11
SMS Reply	353358017784062,F11,OK

3.46 Changing the Tracker Password – F20

SMS Sending	0000,F20, <i>New password</i>
SMS Reply	IMEI,F20,OK
Description	Change the SMS password. Note: The password has four digits in decimal string.
Applicable Model	All
Example	
SMS Sending	0000,F20,1234
SMS Reply	353358017784062,F20,OK

3.47 Initializing the Tracker Password – FAB

SMS Sending	8888,FAB
SMS Reply	IMEI,FAB,OK

Description	The command is used to restore the tracker password to the password before delivery. The command takes effect only when you use the authorized phone number to send the command.
Applicable Model	All
Example	
SMS Sending	8888,FAB
SMS Reply	353358017784062,FAB,OK

If you have any questions, do not hesitate to email us at info@meitrack.com.