



### INSTALLATION NOTES

- To remove cables from existing frame, grab and rock the ends out of position. Frame is not required with STI-3100 spacer.
- Mount STI-3100 spacer. Mark and drill holes as follows:
  - Wall anchors: drill four 1/4" (6.3mm) 1-1/4" deep
  - No wall anchors: drill four 5/32" (3.9mm) 1-1/4" deep
- Install cover by pressing cable end stop into spacer.

**WARNING:** This product can expose you to chemicals including Dichloromethane, which is known to the State of California to cause cancer, and Bisphenol A (BPA), which is known to the State of California to cause birth defects or other reproductive harm. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details. Electronic warranty form at [www.sti-usa.com/wc14](http://www.sti-usa.com/wc14).



USA

## STI-3100 CONDUIT SPACER

All specifications and information shown were current as of publication and are subject to change without notice.



3100IS DEC 2014



EMEA