




## QM2-2S-220A

### Tarjeta de expansión dual SSD M.2 SATA 22110 o 2280



#### Modelos compatibles:

##### [2-Bahías]

TS-251B, TS-251D, TS-253B, TS-253Be, TS-253D

##### [4-Bahías]

TS-431XU, TS-431XU-RP, TS-432XU, TS-432XU-RP, TS-453B, TS-453Be, TS-453BT3, TS-453BU, TS-453BU-RP, TS-453D, TS-463U, TS-463U-RP, TS-463XU, TS-463XU-RP, TS-470, TS-470 Pro, TS-473, TVS-463, TVS-470, TVS-471, TVS-471U, TVS-471U-RP, TVS-472XT, TVS-473, TVS-473e

##### [5-Bahías]

TS-531P, TS-531X, TS-563

##### [6-Bahías]

QVP-63A, TS-653B, TS-653D, TS-670, TS-670 Pro, TS-673, TS-677, TVS-663, TVS-670, TVS-671, TVS-672N, TVS-672XT, TVS-673, TVS-673e, TVS-682, TVS-682T

##### [8-Bahías]

QVP-85A, TS-831X, TS-831X v2, TS-831XU, TS-831XU-RP, TS-832X, TS-832XU, TS-832XU-RP, TS-853BU, TS-853BU-RP, TS-863U, TS-863U-RP, TS-863XU, TS-863XU-RP, TS-870, TS-870 Pro, TS-870U-RP, TS-873, TS-873U, TS-873U-RP, TS-877, TS-877XU, TS-877XU-RP, TS-879 Pro, TS-879U-RP, TS-883XU, TS-883XU-RP, TS-EC879U-RP, TS-EC880 Pro, TS-EC880U, TS-EC880U R2, TVS-863, TVS-863+, TVS-870, TVS-871, TVS-871T, TVS-871U-RP, TVS-872N, TVS-872XT, TVS-872XU, TVS-872XU-RP, TVS-873, TVS-873e, TVS-882, TVS-882BR, TVS-882BRT3, TVS-882ST2, TVS-882ST3, TVS-882T, TVS-EC880

##### [10-Bahías]

TS-1079 Pro, TS-EC1080 Pro, TVS-EC1080, TVS-EC1080+

##### [12-Bahías]

SS-EC1279U-SAS-RP, TS-1231XU, TS-1231XU-RP, TS-1232XU, TS-1232XU-RP, TS-1253BU, TS-1253BU-RP, TS-1263U, TS-1263U-RP, TS-1263XU, TS-1263XU-RP, TS-1270U-RP, TS-1273U, TS-1273U-RP, TS-1277, TS-1277XU, TS-1277XU-RP, TS-1279U-RP, TS-1283XU-RP, TS-EC1279U-RP, TS-EC1279U-SAS-RP, TS-EC1280U, TS-EC1280U R2, TS-h1283XU-RP, TVS-1271U-RP, TVS-1272XU-RP, TVS-1282, TVS-1282T, TVS-1282T3, TVS-EC1280U-SAS-RP, TVS-EC1280U-SAS-RP R2

##### [16-Bahías]

TS-1635, TS-1635AX, TS-1673U, TS-1673U-RP, TS-1677X, TS-1677XU, TS-1677XU-RP, TS-1679U-RP, TS-1683XU-RP, TS-EC1679U-RP, TS-EC1679U-SAS-RP, TS-EC1680U, TS-EC1680U R2, TVS-1672XU-RP, TVS-EC1680U-SAS-RP, TVS-EC1680U-SAS-RP R2

##### [18-Bahías]

SS-EC1879U-SAS-RP, TS-1886XU-RP

##### [24-Bahías]

SS-EC2479U-SAS-RP, TS-2477XU-RP, TS-2483XU-RP, TS-EC2480U, TS-EC2480U R2, TVS-2472XU-RP, TVS-EC2480U-SAS-RP, TVS-EC2480U-SAS-RP R2

##### [15-Bahías]

TVS-1582TU, TVS-EC1580MU-SAS-RP, TVS-EC1580MU-SAS-RP R2

##### [9-Bahías]

TS-977XU, TS-977XU-RP, TS-983XU, TS-983XU-RP, TS-h977XU-RP, TVS-972XU, TVS-972XU-RP

##### [28-Bahías]

TS-2888X