

• FAQ

Q: TV displays with black borders around the edge:

A:1) Adjust the display ratio with the mode switch button;

2) Set TV to full screen mode(full pixel display).

Q: the TV shows "No signal"

A:1) Please check whether there is a HDMI signal input;

2) Try to replace high quality or shorter HDMI cables

3) Try to reduce the resolution of signal source.

• SPECIFICATION

Item	Description
HDMI signal	HDMI1.3, Full compatible with HDCP1.2
Input port	1×HDMI
Output port	4×HDMI
Audio format	PCM
HDMI resolution	480i@60Hz, 480p@60Hz , 576i@50Hz , 576p@50Hz , 720P@50/60Hz,1080p@50/60Hz
Working temperature	0-60°C
Power supply	12V /2A
Power consumption	<10W
Product dimension	214(L)x108.6(W)x25.5(H)mm
Weight	610g
Color	Black

Disclaimer

The product name and brand name may be registered trademark of related manufacturers.TM and ® may be omitted on the user manual. The pictures on the user manual are just for reference, and there may be some slight difference with the real products.We reserve the rights to make changes without further notice to a product or system described herein to improve reliability, function or design.

HDMI 2×2 Video Wall Controller

User Manual

