


"Beyond Your Expectations"



| REQUENCY | LENGTH (L) |
|----------|------------|
| 450 MHz | 14 |
| 455 MHz | 13 3/16" |
| 460 MHz | 12 1/2" |
| 465 MHz | 12" |
| 470 MHz | 11 3/4" |

P/N: 9752

P/N: 9752-3

INSTALLATION INSTRUCTIONS

LMG-450-5

UHF 5 dB Motorola (NMO) Style Mobile Antenna

Mount the LMG-450 as near to the center of the roof, fender or trunk of the vehicle as is practical. Install Motorola style mount and coax assembly as specified by the manufacturers instructions (see NOTE below). Place the gasket around the mount and thread the coil onto the mount. Be sure to tighten the coil sufficiently to ensure mechanical stability and seal against moisture. Do not over-tighten.

Consult the CUT CHART for the nominal exposed tip rod length "L" between the top of the adapter and the base of the center coil. Add one inch to this length to assure an adequate amount of rod below the top of and inside the adapter. Cut the lower end of the rod to this length. Remove any burrs created by the cutting process. Insert the base of the tip rod into the top of the adapter. Use the allen wrench to adjust the length of exposed tip rod to the CUT CHART length "L". To insure reliable performance, it is recommended that a reliable SWR bridge be used to accurately tune the antenna to your required frequency and application.

NOTE: Mount/Coax Assembly may be purchased separately or in a kit with your LMG-450.



New-TRONICS Antenna Corporation One Newtronics Place Mineral Wells, Texas 76067-9563

HWD Kit REV 0

LMG--450-5

(940)-325-1386

Printed in USA