Accessories (Cont.)

MSFCB2 Installation

1. Pull plunger before installation. Depress plungers to lock in place.



FMS1 Installation

1. Remove the adhesive back liner.
2. Press FMS1 to the desired location.