Altronix[®] SMP7CTX Series - Installation Guide

SMP7CTX Series Power Supply Configuration Reference Chart:

Altonit Nodel Miniber	PCC Distinuit	et jule	under fri	Outo of Outo	States Contraction	busic as	and	C CUTO	Totol and
SMP7CTX	-	1	-	-	-	-	1.45	6	
SMP7PMCTX	-	1	-	-	-	Х	1.45	6	
SMP7PMP4	PD4	4	X	-	3.5	Х	1.45	6	
SMP7PMP4CB	PD4CB	4	-	х	2.5	Х	1.45	6	
SMP7PMP8	PD8	8	X	-	3.5	Х	1.45	6	
SMP7PMP8CB	PD8CB	8	-	x	2.5	X	1.45	6	
SMP7PMP16	PD16W	16	X	-	3.5	Х	1.45	6	
SMP7PMP16CB	PD16WCB	16	-	x	2.5	x	1.45	6	

Overview:

Specifications:

These units will convert a 115VAC / 60Hz input, into a regulated 12VDC or 24VDC output up to 6 amp of continuous load current (see specifications).

- Maximum charge current .7 amp.
- Filtered and electronically regulated outputs.
- Built-in charger for sealed lead acid or gel type batteries.
- Automatic switch over to stand-by battery when AC fails (zero voltage drop).
- AC input and DC output LED indicators.
- Short circuit and thermal overload protection.

Power Supply Voltage Output Specifications: *

Output VDC	Switch Position	Max. Load DC
12VDC	SW1 - Closed (Fig. 1B, pg. 3)	6 amp
24VDC	SW1 - Open (Fig. 1B, pg. 3)	6 amp

*Specified at 25° C ambient.

Installation Instructions:

The unit should be installed in accordance with The National Electrical Code and all applicable Local Regulations.

- 1. Mount the unit in desired location.
- 2. Set SW1 on the power supply board to the desired DC output voltage *(Power Supply Voltage Output Specification Chart).*
- 3. Connect AC power to terminals marked [L & N], connect ground to terminal marked [G] (if used).
- 4. Measure output voltage before connecting devices. This helps avoid potential damage.
- 5. Connect devices to be powered:
 - a. For Power Supply Board connect to terminals marked [+ DC -].
 - b. For Power Distribution Module(s) connect devices to be powered to terminal pairs 1 to 4 marked

- Complete with power supply, power distribution module (when applicable), enclosure, cam lock & battery leads.
- Power on-off switch. *Supervised models only:*
- AC fail supervision (form "C" contacts).
- Low battery supervision (form "C" contacts).

[1P & 1N through 4P & 4N] (Fig. 2, pg. 3), 1 to 8 marked [1P & 1N through 8P & 8N] (Fig. 3, pg. 3)

or 1 to 16 marked [1P & 1N through 16P & 16N] (Fig. 4, pg. 3) carefully observing correct polarity.

*Note: Power switch is used to disconnect the L (HOT) terminal from the rest of the board. When servicing the unit, AC mains should be removed.

6. When using stand-by batteries, they must be lead acid or gel type. Connect battery to terminals marked [- BAT +] (battery leads included). Use two (2) 12VDC batteries connected in series for 24VDC operation.

Note: When batteries are not used a loss of AC will result in the loss of output voltage.

Supervised models only:

7. Connect appropriate signaling notification devices to AC Fail & Low Bat supervisory relay outputs marked [NO, C, NC] (*Fig. 1A, below*).

Fig. 1

CAUTION: De-energize unit prior to servicing. For continued protection against fire hazard replace fuse with the same type and rating 3.5A, 250V.

Replace protective cover on the fuse of the power supply board, before energizing unit.



Power Distribution Module(s):





LED Diagnostics:

Red (DC)	Green (AC)	Power Supply Status	
ON	ON	Normal operating condition.	
ON	OFF	Loss of AC, Stand-by battery supplying power.	
OFF	ON	No DC output.	
OFF	OFF	Loss of AC. Discharged or no stand-by battery. No DC output.	

Terminal Identification:

Terminal Legend	Function/Description
L, G, N	Connect 115VAC to these terminals: L to Hot, N to Neutral, G to ground (if used).
+ DC -	12VDC / 24VDC @ 6 amp continuous non-power limited output.
*AC FAIL N.O., C, N.C.	Used to notify loss of AC power, e.g. connect to audible device or alarm panel. Relay normally energized when AC power is present. Contact rating 1 amp @ 120VAC / 28VDC
*Low Battery N.O., C, N.C.	Used to indicate low battery condition, e.g. connect to alarm panel. Relay normally energized when DC power is present. Contact rating 1 amp @ 120VAC / 28VDC Low battery threshold: 12VDC output threshold set @ approximately 10.5VDC, 24VDC output threshold set @ approximately 21VDC.
- BAT +	Stand-by battery connections. Maximum charge rate .7 amp.

* Note: Supervised models only

PD4/PD4CB/PD8/PD8CB/PD16W/PD16WCB - Power Distribution Module

	Terminal Legend		Function/
PD4/PD4CB	PD8/PD8CB	PD16W/PD16WCB	Description
1P to 4P	1P to 8P	1P to16P	Positive DC power outputs.
1N to 4N	1N to 8N	1N to 16N	Negative DC power outputs.

Enclosure Dimensions:

13"H x 13.5"W x 3.25"D



Altronix is not responsible for any typographical errors.

