# AC-425x-B Series

Expandable 4-Reader Networked Access Control Panel Hardware Installation and User Guide

<u>Models</u>: AC-425-B AC-425-DIN AC-425IP-B AC-425IP-DIN





## Copyright © 2018 by Rosslare. All rights reserved.

This manual and the information contained herein are proprietary to ROSSLARE ENTERPRISES LIMITED and/or its related companies and/or subsidiaries' (hereafter: "ROSSLARE"). Only ROSSLARE and its customers have the right to use the information.

No part of this manual may be re-produced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of ROSSLARE.

ROSSLARE owns patents and patent applications, trademarks, copyrights, or other intellectual property rights covering the subject matter in this manual.

TEXTS, IMAGES, AND ILLUSTRATIONS INCLUDING THEIR ARRANGEMENT IN THIS DOCUMENT ARE SUBJECT TO THE PROTECTION OF COPYRIGHT LAWS AND OTHER LEGAL RIGHTS WORLDWIDE. THEIR USE, REPRODUCTION, AND TRANSMITTAL TO THIRD PARTIES WITHOUT EXPRESS WRITTEN PERMISSION MAY RESULT IN LEGAL PROCEEDINGS.

The furnishing of this manual to any party does not give that party or any third party any license to these patents, trademarks, copyrights or other intellectual property rights, except as expressly provided in any written agreement of ROSSLARE.

ROSSLARE reserves the right to revise and change this document at any time, without being obliged to announce such revisions or changes beforehand or after the fact.

# Table of Contents

1.	Introduction	8
1.1	AxTraxNG	9
1.1.1	Client-Server Structure	10
1.1.2	Configurable Links	10
1.1.3	Fingerprint Recognition	10
2.	Technical Specifications	11
2.1	AC-425x-DIN	11
2.2	AC-425x-B Installed in ME-1015	12
3.	AC-425x-B Panel Setup	14
3.1	Inputs Wiring – Non-Supervised Inputs	15
3.2	Inputs Wiring – Supervised Inputs	16
3.3	Outputs Wiring	16
3.4	Power Supply	17
3.5	AC-425x-B Wiring Communications	19
3.6	Readers	19
3.7	MD-IO84B	20
3.8	MD-D048	20
4.	Input and Output Connections	21
4.1	Input Types	21
4.1.1	Normally Open Input Connection	21
4.1.2	Normally Closed Input Connection	22
4.1.3	Normally Open Supervised Single EOL Resistor Input Connection	
4.1.4	Normally Open Supervised Double EOL Resistor Input Connection	23
4.1.5	Normally Closed Supervised Single EOL Resistor Input Connection	24
4.1.6	Normally Closed Supervised Double EOL Resistor Input Connection	
4.2	Inputs Description	25

# **Table of Contents**

4.2.1	Request-to-Exit Button (REX) Input	25
4.2.2	Door Monitor Input	26
4.2.3	General Purpose Inputs	
4.3	Outputs	27
4.3.1	Door Lock	27
4.4	Card Readers and Keypads	
5.	AC-425x-B Hardware Settings	30
5.1	DIP Switch Configuration	
5.2	AC-425x-B Panel Baud Rate	
5.3	AC-425x-B Panel Type	
5.4	AC-425x-B Panel Address	
6.	Communications	37
6.1	Serial Network Connection	
6.1.1	RS-232 Connection to the Computer	
6.1.2	RS-485 Connection to the Computer	
6.1.3	Daisy Chaining	
6.2	TCP/IP Network Connection	40
6.2.1	LAN and WAN Requirements	40
6.2.2	LAN and WAN Requirements	41
A.	Declaration of Conformity	42
B.	Radio Equipment Directive (RED)	43
C.	RoHS Directive	44
	Limited Warranty	

# List of Figures

Figure 1: AC-425x-B Panel Layout	9
Figure 2: Sample AC-425x-B Configuration	14
Figure 3: Inputs Wiring – Non-supervised Inputs	15
Figure 4: Door Lock – Failed Close	16
Figure 5: Door Lock – Failed Open	17
Figure 6: Wiring Between PM-10 and AC-425x-B	18
Figure 7: AC-425x-B Wiring Communications	19
Figure 8: Reader Wiring	20
Figure 9: Connector Location for MD-IO84B or MD-D04B Expansions	20
Figure 10: Normally Open Input Connection	22
Figure 11: Normally Closed Input Connection	22
Figure 12: Normally Open Supervised Input (Single Resistor)	23
Figure 13: Normally Open Supervised Input (Double Resistor)	23
Figure 14: Normally Closed Supervised Input (Single Resistor)	24
Figure 15: Normally Closed Supervised Input (Double Resistor)	25
Figure 16: DIP Switches	
Figure 17: RS-232 Panel Connection to PC	37
Figure 18: RS-485 Panel Connection to PC	
Figure 19: Daisy Chaining	
Figure 20: MD-N32 Configuration Connecting a Single Panel	40
Figure 21: Connecting a Single Control Panel with MD-N32	41
Figure 22: Connecting Multiple Access Control Panels with MD-N32	41

# List of Tables

Table 1: DIP Switches and Their Functions	
Table 2: Switch Baud Rates	31
Table 3: Possible Hardware Settings	31
Table 4: Available Panel Addresses	35
Table 5: RS-232 Connection	

# Notice and Disclaimer

This manual's sole purpose is to assist installers and/or users in the safe and efficient installation and usage of the system and/or product, and/or software described herein.

# BEFORE ATTEMPTING TO INSTALL AND/OR USE THE SYSTEM, THE INSTALLER AND THE USER MUST READ THIS MANUAL AND BECOME FAMILIAR WITH ALL SAFETY REQUIREMENTS AND OPERATING PROCEDURES.

- The system must not be used for purposes other than those for which it was designed.
- The use of the software associated with the system and/or product, if applicable, is subject to the terms of the license provided as part of the purchase documents.
- ROSSLARE exclusive warranty and liability is limited to the warranty and liability statement provided in an appendix at the end of this document.
- This manual describes the maximum configuration of the system with the maximum number of functions, including future options. Therefore, not all functions described in this manual may be available in the specific system and/or product configuration you purchased.
- Incorrect operation or installation, or failure of the user to effectively maintain the system, relieves the manufacturer (and seller) from all or any responsibility for consequent non-compliance, damage, or injury.
- The text, images and graphics contained in the manual are for the purpose of illustration and reference only.
- All data contained herein subject to change without prior notice.
- In no event shall manufacturer be liable for any special, direct, indirect, incidental, consequential, exemplary, or punitive damages (including, without limitation, any and all damages from business interruption, loss of profits or revenue, cost of capital or loss of use of any property or capital or injury).
- All graphics in this manual are for reference only, some deviation between the image(s) and the actual product may occur.
- All wiring diagrams are intended for reference only, the photograph or graphic of the PCB(s) are intended for clearer illustration and understanding of the product and may differ from the actual PCB(s).

Note

# 1. Introduction

In this manual, unless otherwise stated, "AC-425x-B" refers to both the regular AC-425-B and the AC-425IP-B moels.

The AC-425x-B access control panel is a state-of-the-art networked access controller, employing the latest technology to meet the requirements of the market.

The state-of-the-art dual/quad door AC-425x-B networked access controller is the backbone of medium scale security systems handling up to 30,000 users and 8184 doors.

Each AC-425x-B access control unit (ACU) supports four readers (In/Out) of various formats including standard Wiegand 26-bit. Installations can also have one reader per door.

The AC-425x-B comes in two models:

- AC-425-B standard model
- AC-425IP-B supports TCP/IP connection

Driven by Rosslare's powerful, flexible and easy-to-use AxTraxNG<sup>™</sup> software, the system provides an ideal, modular and expandable solution for commercial and institutional needs. It provides seamless integration with Rosslare's range of RFID proximity, PIN, Proximity & PIN, smartcard and biometric readers with Rosslare's selection of RFID credentials.

The AC-425x-B is ready for installation with a mountable & lockable metal enclosure integrated with transformer, power supply/charger, sounder and control board.


Using onboard RS-232/485, Ethernet TCP/IP (AC-425IP-B model only), multiple local or remote sites, door sub-networks can connect to the AxTraxNG Client/Server PC software running on Microsoft<sup>®</sup> Windows<sup>®</sup> 98/ME & NT/2000/XP/7 operating systems.


The AC-425x-B consists of the following components:

- AC-425x-B controller board
- Panel enclosure
- PM-10 management board
- Power transformer
- =  $4 \times 2.2 \text{ k}\Omega$  and  $4 \times 8.2 \text{ k}\Omega$  resistors for the supervised inputs

### Introduction

Figure 1 shows the layout of the AC-425x-B panel.





#### 1.1 AxTraxNG

The AxTraxNG software system is custom designed to set up, manage, and supervise all aspects of an access panel network.

It offers the following capabilities:

Parameter	Value
Users capacity	30,000
Unauthorized users	30,000
Access groups	30,000
Number of panels in system	1023
Number of doors in system	8184



These options are software and firmware dependent, and may change in later releases or revisions.

### Introduction

#### 1.1.1 Client-Server Structure

AxTraxNG operates through a dedicated AxTraxNG server computer, which communicates with the access control panels and can serve an unlimited number of network clients.

The server also runs the system's SQL database, which contains settings and definitions for access control across the entire facility. System users can define new cards holders and users, and control access permissions. The system includes tools for database backup, input, and export of previous configurations and automatic backup on a periodic basis.

AxTraxNG supports all panel types and offers scalability and flexibility in addition to a range of advanced control features.

#### 1.1.2 Configurable Links

The system's configurable links model makes it possible to trigger any chosen output automatically or report a configurable alarm, based on a selected input. This allows easy integration with other access systems such as intruder alarms, CCTV systems, and elevator controls.

AxTraxNG can also define a selected set of operations, which are defined in configurable links, when a panel registers a specified user or group of users. This can be useful, for example, in elevator control systems. The system can assign users with counters, allowing a limited number of entries to each panel.

#### 1.1.3 Fingerprint Recognition

AxTraxNG can share user details with Rosslare's BioTrax software system. The BioTrax system can then download all selected user information to an AYC-W6500 fingerprint reader.

Fingerprint recognition was not evaluated by UL.

Note

# 2. Technical Specifications

### 2.1 AC-425x-DIN

# **Technical Specifications**

Electrical Characteristics					
Operating Voltage	12 VDC, 1.5 A from a regulated power supply				
Maximum Input Current		-425	Standby: 80 mA		
			Maximum: 325 mA		
		-425IP	Standby: 120 mA		
			Maximum: 370 mA		
General Inputs	• 4	• 4 supervised high impedance inputs			
		•	d inputs when using MD-D02B or MD-		
	IO84B expansion boards				
		Maximum voltage			
Relay Outputs		Form C 5 Amp			
		3 outputs when u poards	ising MD-D02B or MD-IO84B expansion		
Reader Ports	• 2	2 reader ports, 4	reader ports when using MD-D02B		
	• (	Communication: \	Wiegand (D0, D1) or Clock & Data (C, D)		
	• (	Output voltage to	reader: 12 VDC		
	• 1	• Max. current to reader: 245 mA			
	• 1	ED control outpu	ut and Tamper Input		
Visual Indicators	11	11 LEDs for outputs and communication status			
Audio		Sounder output for use with compatible speakers provide chime, bell and siren signals			
Battery Standby Time	3 h	ours with a 12 V,	7 Ah lead acid battery		
Communication Characteristics					
RS-485 / RS-232	• 6	RS-485 or optiona	al RS-232		
	•	• RS-485 connection by terminal block or MD-14U connector			
	• 6	RS-232 connection by terminal block			
RS-232	Ter	minal Block			
RS-485	Мо	lex and Terminal	Block		
TCP/IP	On	On-board RJ-45 connector			
	(fur	functional on AC-425IP models only)			
Selectable Communication Speed	960	600, 19200, 57600, 115200 bps			
Environmental Characteristics					
Operating Temperature Range		0°C to 49°C (32°F to 120°F)			
Operating Humidity Range		0 to 85% (non-condensing)			
Dimensions					
Height x Width x Depth		193 x 136.5 x 3	9 mm (7.6 x 5.4 x 1.5 in.)		
Weight		0.36 kg (12.7 oz)			

#### 2.2 AC-425x-B Installed in ME-1015

# **Technical Specifications**

Electrical Characteristics - Switch	
Operating Voltage	90 ~ 265 VAC, 50 ~ 60 Hz from mains power
Maximum Input Current	1.5 A
Output Power	15 VDC, 4 A (60 Watts) to the power management board
Electrical Characteristics - Power	Management Board (PM-10)
Input Power 15 VDC, 4 A to the power management board	
Output Power	Two PTC fused outputs, each provides 13.8 VDC, 2 A
	One output for controller and readers
	One output for locks
Battery Charger	13.8 VDC, 300 mA for 12 VDC, 7 Ah Lead Acid Battery
Speaker	0.5 Watt, 8 Ohm
Light Bar	0.3 Watt for LED light
Environmental Characteristics	
Operating Temperature Range	0°C to 49°C (32°F to 120°F)
Operating Humidity Range	0 to 85% (non-condensing)
Dimensions	
Height x Width x Depth	365 x 264 x 97 mm (14.4 x 10.4 x 3.8 in.)
Weight	3.4 kg (7.5 lb)

# 3. AC-425x-B Panel Setup

Each AC-425x-B panel controls 2 or 4 doors (up to 8 doors with MD-D04B). The panels connect together in a network and are controlled by a central server computer, running the AxTraxNG software system.

Figure 2 shows an example setup for a network of AC-425x-B access control panels.




Figure 2: Sample AC-425x-B Configuration

Note

#### 3.1 Inputs Wiring – Non–Supervised Inputs

Figure 3 presents a detailed view of the non-supervised inputs and their connection options.




Figure 3: Inputs Wiring - Non-supervised Inputs

#### 3.2 Inputs Wiring – Supervised Inputs


When wiring the AC-425x-B for supervised inputs, resistors should be placed on the input switch and not on the terminal block.


For more details, refer to Chapter 4.

#### 3.3 Outputs Wiring

Figure 4 and Figure 5 illustrate wiring for two main types of 12 VDC electrical release mechanisms. Other electrical devices can be switched using the voltage free relay contacts.

#### Figure 4: Door Lock – Failed Close





#### 3.4 Power Supply

Figure 6 illustrates wiring between the PM-10 power management board and the AC-425x-B. Make sure the connection polarity is correct, (+) to (+) and (-) to (-). Connect the power to the input power terminals of the control panel. It is recommended to add a 12 VDC lead acid backup battery (requires the ME-1015 Power Management Enclosure) to have uninterrupted operation in case main power supply fails. A 12 V, 7 AH battery provides 3 hours of backup operation.





Figure 6: Wiring Between PM-10 and AC-425x-B

#### 3.5 AC-425x-B Wiring Communications

Figure 7 presents a detailed view of the access control panel with all it wiring communications.



#### Figure 7: AC-425x-B Wiring Communications

#### 3.6 Readers

Note

Proximity and keypad readers are supplied with a limited cable. The color of the cable cover represents the cable's function according to Wiegand standards (Figure 8).

When extending the cable distance, be careful with the color of the cable cover.

Refer to the reader specifications for the maximum cable length (typically 150 m with an 18 AWG cable).

	Red +12V		Tamper	Purple	$\square$
00	Black (-)		G.LED	Brown	
	Green D0		D1	White	
	White D1		DO	Green	11
	Brown G.LED		(-)	Black	11
	Purple Tamper		+12V	Red	رىت
				,	

Figure 8: Reader Wiring

#### 3.7 MD-IO84B

The MD-IO84B is an optional I/O expansion board that adds 4 relay outputs and 8 supervised inputs to the Access Control Panel. Attach the MD-IO84B to the AC-425x-B's expansion slot, as marked in red in Figure 9).




Figure 9: Connector Location for MD-IO84B or MD-D04B Expansions

For more information, see the MD-IO84B Installation and User Guide.

#### 3.8 MD-D04B

The MD-D04B is an optional reader expansion board that adds 4 readers, 4 relay outputs and 4 supervised inputs to the access control panel. Attach the MD-D04B to the AC-425x-B's expansion slot, as marked in red in Figure 9.

For more information, see the MD-D04B Installation and User Guide.

# 4. Input and Output Connections

This chapter describes the AC-425x-B access control panel's input and output connections.

#### 4.1 Input Types

There are four input types:

- Normally Closed (N.C.)
- Normally Open (N.O.)
- Single EOL resistor
- Double EOL resistor

Inputs IN1, IN2, IN3, and IN4 may be configured individually as either supervised or nonsupervised inputs. Use the AxTraxNG system to configure each input separately.

Non-supervised inputs have two states:

- Normal
- Abnormal

Supervised inputs have three states:

- Normal
- Abnormal
- Trouble

The Trouble state is caused by either tampering with the input circuit or by faulty hardware installation. Once an input is configured as a supervised input, add a resistor of 2.2 k $\Omega$ , of 8.2 k $\Omega$ , or both on the input circuit. See the following diagrams.

#### 4.1.1 Normally Open Input Connection

A Normally Open Input has 2 states:


Switch Open – Normal State:

Loop resistance = Infinite (open circuit)

Switch Closed – Abnormal State:

Loop resistance = 0 (short circuit)

Figure 10: Normally Open Input Connection





4.1.2 Normally Closed Input Connection

A Normally Closed Input has two states:

- Switch Closed Normal State:
  - Loop resistance = 0 (short circuit)
- Switch Open Abnormal State:

Loop resistance = Infinite (open circuit)





4.1.3 Normally Open Supervised Single EOL Resistor Input Connection

Connect an 8.2  $k\Omega$  resistor in parallel to the input switch contacts.

A Normally Open Supervised Input has 3 states:

Switch Open – Normal State:

Loop resistance = 8.2 k $\Omega$ 


Switch Closed – Abnormal State:


### Input and Output Connections

Loop resistance = 0 (short circuit)

Open circuit across input terminals - Trouble State:

Loop resistance = Infinite (open circuit).





#### 4.1.4 Normally Open Supervised Double EOL Resistor Input Connection

Connect a 2.2 k $\Omega$  resistor in series to the input switch contacts.

Connect an 8.2 k $\Omega$  resistor parallel to the input switch contacts.

A Normally Open Supervised Input has 3 states:


Switch Open - Normal State: н.

Loop resistance = 10.4 k $\Omega$ 

Switch Closed - Abnormal State:

Loop resistance = 2.2 k $\Omega$ 

Open circuit (infinite loop resistance) or short circuit (0 resistance) across input terminals - Trouble State



#### Figure 13: Normally Open Supervised Input (Double Resistor)

### Input and Output Connections

#### 4.1.5 Normally Closed Supervised Single EOL Resistor Input Connection

Connect a 2.2 k $\Omega$  resistor in series to the input switch contacts.

A Normally Closed Supervised Input has 3 states:


- Switch Closed Normal State:
  Loop resistance = 2.2 kΩ
- Switch Open Abnormal State:

Loop resistance = Infinite (open circuit)

Short circuit across input terminals – Trouble State:

Loop resistance = 0 (short circuit)





4.1.6 Normally Closed Supervised Double EOL Resistor Input Connection

Connect a 2.2 k $\Omega$  resistor in series to the input switch contacts.

Connect an 8.2 k $\Omega$  resistor parallel to the input switch contacts.

A Normally Closed Supervised Input has 3 states:

Switch Closed – Normal State:

Loop resistance = 2.2 k $\Omega$ 

Switch Open – Abnormal State:

Loop resistance = 10.4 k $\Omega$ 

Open circuit (infinite loop resistance) or short circuit (0 resistance) across input terminals
 – Trouble State




Figure 15: Normally Closed Supervised Input (Double Resistor)

#### 4.2 Inputs Description

#### 4.2.1 Request-to-Exit Button (REX) Input

Use the REX input to open a door directly. Typically, the REX input is connected to a Normally Open push button that is located inside the premises. The push button is generally located in an easy-to-access position and opens a door without reading a proximity card or PIN code.

Scenario	Setting
Two readers per door	Door 1 – IN 1
	Door 2 – IN 2
One reader per door	Door 1 – IN 1
	Door 2 – IN 2
	Door 3 – IN 3
	Door 4 – IN 4

REX input functions when using MD-D04B:

Scenario	Setting
Two readers per door	Door 1 – IN1
	Door 2 – IN2
	Door 5 – IN5
	Door 6 – IN6
One reader per door	Door 1 – IN1
	Door 2 – IN2
	Door 3 – IN3
	Door 4 – IN4
	Door 5 – IN5
	Door 6 – IN6
	Door 7 – IN7

### Input and Output Connections

Door 8 - IN8

#### 4.2.2 Door Monitor Input

The Door Monitor input typically connects to a Normally Closed door sensing micro-switch for door status monitoring. Using Door Monitor enables many advanced options such as door forced alarm, door held open warnings, interlocking doors and more. Door monitor feature is only available when the system is defined as a two reader per door. The following should be defined:

Scenario	Setting
Two readers per door	Door 1 – IN3
	Door 1 – IN4

Dedicated Input functions when using MD-D04B:

Scenario	Setting
Two readers per door	Door 1 – IN3
	Door 2 – IN4
	Door 3 – IN7
	Door 4 – IN8

#### 4.2.3 General Purpose Inputs

These are free inputs that can be used for various functions. This function is only available with the MD-IO84B expansion. The following should be defined:

Scenario	Setting
Single door controller	Door 1 – IN 2
	Door 1 – IN 2A
Double door controller	(no general purpose inputs available)

General purpose inputs are suitable for most uses. For example, they might be used to detect tampering, to activate alarm sensors, or to monitor a power supply failure.

General purpose input functions when using MD-IO84B or MD-D04B:

Unit	Expansions
MD-IO84B	IN5 to IN12
MD-D04B	IN5 to IN8 except the dedicated inputs

### Input and Output Connections

#### 4.3 Outputs

Rosslare Security recommends the use of suppression diodes for all outputs that activate an inductive load.

#### 4.3.1 Door Lock

There are two types of door locking devices:

- Fail open (fail secure)
- Fail close (fail safe)

The following should be defined:

Scenario	Setting
Two readers per door	Door 1 – OUT 1
	Door 2 – OUT 2
One reader per door	Door 1 – OUT 1
	Door 2 – OUT 2
	Door 3 – OUT 3
	Door 4 – OUT 4


Door outputs when using MD-D04B:

Į

Note

Scenario	Setting
Two readers per door	Door 1 – OUT 1
	Door 2 – OUT 2
	Door 3 – OUT 5
	Door 4 – OUT 6
One reader per door	Door 1 – OUT 1
	Door 2 – OUT 2
	Door 3 – OUT 3
	Door 4 – OUT 4
	Door 5 – OUT 5
	Door 6 – OUT 6
	Door 7 – OUT 7
	Door 8 – OUT 8

The output can sink current from any power supply (see Section 3.4).



#### 4.4 Card Readers and Keypads

Each access control panel can be connected to a maximum of four readers or 8 readers when using MD-D04B. There are three available types of reader:

- Card readers
- Keypads
- Dual keypad card readers

A keypad is required for any reader mode that requires PIN code entries, such as "Card or PIN", "PIN Only" or "Card and PIN (Secured mode)".

When connecting a reader, the following should be defined:

Scenario	Setting
Two readers per door	Door 1 – Reader 1 IN/OUT
	Door 1 – Reader 3 IN/OUT
	Door 2 – Reader 2 IN/OUT
	Door 2 – Reader 4 IN/OUT
One readers per door	Door 1 – Reader 1 IN/OUT
	Door 2 – Reader 2 IN/OUT
	Door 3 – Reader 3 IN/OUT
	Door 4 – Reader 4 IN/OUT

When using the MD-D04B, the following should be defined:

Scenario	Setting
Two readers per door:	Door 1 – Reader 1 IN/OUT
	Door 1 – Reader 3 IN/OUT
	Door 2 – Reader 2 IN/OUT
	Door 2 – Reader 4 IN/OUT
	Door 3 – Reader 5 IN/OUT
	Door 3 – Reader 7 IN/OUT
	Door 4 – Reader 6 IN/OUT
	Door 4 – Reader 8 IN/OUT
One readers per door:	Door 1 – Reader 1 IN/OUT
	Door 2 – Reader 2 IN/OUT
	Door 3 – Reader 3 IN/OUT
	Door 4 – Reader 4 IN/OUT
	Door 5 – Reader 5 IN/OUT
	Door 6 – Reader 6 IN/OUT
	Door 7 – Reader 7 IN/OUT

### Input and Output Connections

Scenario	Setting
	Door 8 – Reader 8 IN/OUT

Use the AxTraxNG software to set the readers for IN or OUT use and to set the data transmission format for each reader.

The reader's tamper output connects to the access control panel's Reader-Tamper input. If the reader is interfered with, an alarm can be generated.

The panel's Reader G.LED output activates the reader's green LED input when operating in "Card and PIN" secure mode. While this mode is in force, users must enter a PIN on the keypad immediately after entering the card.

The controller activates the LED control for 2 seconds when an access granted event occurs.

# 5. AC-425x-B Hardware Settings

#### 5.1 DIP Switch Configuration

The DIP switches in the access control panel determine the baud rates for serial communication, control panel type, and the device address, as summarized in Table 1.

DIP Switch	Function
1	
2	The panel's communication baud rate
3	The panel type defines the number of readers for each door – one or two readers per door. This also affects the number of doors controlled by the panel.
4 5 6 7 8	The access control panel's RS-485 network address


**Table 1: DIP Switches and Their Functions** 



Power down the access control panel before changing the DIP switch settings. After changes have been made, restart the panel. The new settings are automatically defined after

power up.

In general, the up position is ON and the down position is OFF as demonstrated in Figure 16.



#### 5.2 AC-425x-B Panel Baud Rate

The AC-425x-B panel serial port baud rate, set in DIP switches 1 and 2, defines the communication speed for connecting with a PC in a network connection.

The default baud rate is set to 9600 bits per second.

Table 2 lists the status of Switches 1 and 2 and the baud rate:

Switch 1	Switch 2	Baud Rate
Off	Off	9600
Off	On	19200
On	Off	115200
On	On	57600

Table 2: Switch Baud Rates



The access control panel baud rate must be identical to the AxTraxNG Network configuration of baud rate.

#### 5.3 AC-425x-B Panel Type

The AC-425x-B panel type is defined using the third DIP switch. There are two panel types: a panel with one reader per each door or a panel with two readers per each door. This DIP switch setting influences the number of readers per door in the panel.

The default AC-425x-B panel setting is for two readers per each door.

- Off Defines using two readers for each door. Panel controls two or four doors when MD-D04B is installed.
- On Using one reader for each door. Panel controls four doors or eight doors when MD-D04B installed.

Select the appropriate DIP switch setting to operate the panel as either a single door, a double door, or four doors (see Section 5.3).

Access control panels, configured as either single door or double door controllers, have two readers, IN or OUT. Access control panels configured with the MD-D04B expansion as either double door or four-door controllers have four readers.

Connectors	Description	Setup	
Two readers per	door:		
Outputs	Door 1 Lock output	(OUT 1)	
	Door 2 Lock output	(OUT 2)	
	General purpose output	(OUT 3)	

Table 3: Possible Hardware Settings

Connectors	Description	Setup
	General purpose output	(OUT 4)
Inputs	Door 1: Request to exit	(IN 1)
	Door monitor input	(IN 3)
	Door 2: Request to exit	(IN 2)
	Door monitor input	(IN 4)
Readers	Reader1 – Door1	Door Entry or Exit
	Reader2 – Door2	Door Exit or Entry
	Reader3 – Door1	Door Entry or Exit
	Reader4 – Door2	Door Exit or Entry
One reader per	door:	
Outputs	Door1 Lock output	(OUT 1)
	Door2 Lock output	(OUT 2)
	Door3 Lock output	(OUT 3)
	Door4 Lock output	(OUT 4)
Inputs	Door1 Request to exit	(IN 1)
	Door2 Request to exit	(IN 2)
	Door3 Request to exit	(IN 3)
	Door4 Request to exit	(IN 4)
Readers	Reader1	(Door1 IN/OUT)
	Reader2	(Door2 IN/OUT)
	Reader3	(Door3 IN/OUT)
	Reader4	(Door4 IN/OUT)
Two readers per	door with 8 readers (MD-D04B):	
Outputs	Door1 Lock output	(OUT 1)
	Door2 Lock output	(OUT 2)
	Door3 Lock output	(OUT 5)
	Door4 Lock output	(OUT 6)
Inputs	Door1 Request to exit	(IN 1)
	Door1 monitor input	(IN 3)
	Door2 Request to exit	(IN 2)
	Door2 monitor input	(IN 4)
	Door3 Request to exit	(IN 5)
	Door3 monitor input	(IN 7)
	Door4 Request to exit	(IN 6)
	Door4 monitor input	(IN 8)

# AC-425x-B Hardware Settings

Connectors	Description	Setup
Readers	Reader1	(Door1 IN/OUT)
	Reader2	(Door2 OUT/IN)
	Reader3	(Door1 IN/OUT)
	Reader4	(Door2 OUT/IN)
	Reader5	(Door3 IN/OUT)
	Reader6	(Door4 OUT/IN)
	Reader7	(Door3 IN/OUT)
	Reader8	(Door4 OUT/IN)
One reader per o	door with 8 readers (MD-D04B)	
Outputs	Door1 Lock output	(OUT 1)
	Door2 Lock output	(OUT 2)
	Door3 Lock output	(OUT 3)
	Door4 Lock output	(OUT 4)
	Door5 Lock output	(OUT 5)
	Door6 Lock output	(OUT 6)
	Door7 Lock output	(OUT 7)
	Door8 Lock output	(OUT 8)
nputs	Door1 Request to exit	(IN 1)
	Door2 Request to exit	(IN 2)
	Door3 Request to exit	(IN 3)
	Door4 Request to exit	(IN 4)
	Door5 Request to exit	(IN 5)
	Door6 Request to exit	(IN 6)
	Door7 Request to exit	(IN 7)
	Door8 Request to exit	(IN 8)
Readers	Reader1	(Door1 IN/OUT)
	Reader2	(Door2 OUT /IN)
	Reader3	(Door3 IN/OUT)
	Reader4	(Door4 OUT /IN)
	Reader5	(Door5 IN/OUT)
	Reader6	(Door6 OUT /IN)
	Reader7	(Door7 IN/OUT)
	Reader8	(Door8 OUT /IN)

# AC-425x-B Hardware Settings

#### 5.4 AC-425x-B Panel Address

The last five DIP switches are used to set the binary code of the access control panel internal network address. The default access control panel address is "1".



For successful communications, the DIP switch must match the address set in the AxTraxNG software.

Table 4 displays the 32 address settings available:

### AC-425x-B Hardware Settings

Address	Switch 4	Switch 5	Switch 6	Switch 7	Switch 8
1	OFF	OFF	OFF	OFF	OFF
2	OFF	OFF	OFF	OFF	ON
3	OFF	OFF	OFF	ON	OFF
4	OFF	OFF	OFF	ON	ON
5	OFF	OFF	ON	OFF	OFF
6	OFF	OFF	ON	OFF	ON
7	OFF	OFF	ON	ON	OFF
8	OFF	OFF	ON	ON	ON
9	OFF	ON	OFF	OFF	OFF
10	OFF	ON	OFF	OFF	ON
11	OFF	ON	OFF	ON	OFF
12	OFF	ON	OFF	ON	ON
13	OFF	ON	ON	OFF	OFF
14	OFF	ON	ON	OFF	ON
15	OFF	ON	ON	ON	OFF
16	OFF	ON	ON	ON	ON
17	ON	OFF	OFF	OFF	OFF
18	ON	OFF	OFF	OFF	ON
19	ON	OFF	OFF	ON	OFF
20	ON	OFF	OFF	ON	ON
21	ON	OFF	ON	OFF	OFF
22	ON	OFF	ON	OFF	ON
23	ON	OFF	ON	ON	OFF
24	ON	OFF	ON	ON	ON
25	ON	ON	OFF	OFF	OFF
26	ON	ON	OFF	OFF	ON
27	ON	ON	OFF	ON	OFF
28	ON	ON	OFF	ON	ON
29	ON	ON	ON	OFF	OFF
30	ON	ON	ON	OFF	ON
31	ON	ON	ON	ON	OFF
32	ON	ON	ON	ON	ON

#### Table 4: Available Panel Addresses

### AC-425x-B Hardware Settings

Note

The AC-425x-B panel address is defined in the AxTraxNG software.

Ø The DIP switch and the software must be set to the same address.

Communication lines are used to upload and download information between the AC-425x-B panel and the AxTraxNG server. When the access control panel and the computer are communicating, the system's two LEDs flash accordingly.

- The RX LED flashes when the controller receives data
- The TX LED flashes when the controller transmits data

The access control panel address is defined in the AxTraxNG software.

It is important that the DIP switch and the software are set to the same address.

There are three connection modes:

Note

ß

Note

- Serial Network with RS-232
- Serial Network with RS-485
- TCP/IP Network (AC-425IP-B model only)

#### 6.1 Serial Network Connection

The computer serial port controlling the access control panel is set from within the AxTraxNG server. The default bitrate is 9600 bps for direct connection to the computer.

When using an RS-232 connector, only one access control panel can be linked to each communication port on the computer. Use an RS-485 connection if you wish to connect additional panels to the primary control panel already connected to the COM port.


The J1 switch must be set to the correct position to select the RS-232 communication.

#### 6.1.1 RS-232 Connection to the Computer

Set the J1 switch to the RS-232 position.

The RS-232 connection can only connect a single access control panel to the computer (Figure 17).

Figure 17: RS-232 Panel Connection to PC



The distance between the computer and the access control panel must be no more than 150 feet (50 meters).

If the baud rate is increased to 57600 or beyond, the distance must be no more than 30 feet (10 meters).

Access Control Panel	DB9 Connector	DB25 Connector
GND	Pin 5	Pin 7
Tx	Pin 2	Pin 3
Rx	Pin 3	Pin 2


Table 5: RS-232 Connection

#### 6.1.2 RS-485 Connection to the Computer

Set the J1 switch to the RS-485 position.

Using the RS-485, up to 32 access control panels can be linked together and connected to a single communication port on the computer (Figure 18).





Use the RS-485 interface for situations where there are multiple controllers connected. The serial port used to control the access control panel is assigned within the AxTraxNG software.


The AC-425x-B supports the 2-wire RS-485 interface, which can significantly increase the distance between the server and the last panel. To use the RS-485 interface, the panels must be connected in a daisy-chain formation with an MD-14U RS-485 to RS-232 adapter (Section 6.1.3).



The recommended cable type to be used is STP cat5 (shielded twisted pair category 5). We recommend using a 20-24-AWG cable.

#### 6.1.3 Daisy Chaining

You can connect up to 32 panels to a single serial line using a daisy-chain formation, which is done by drop-down RS-485 wiring (Figure 19).




#### Figure 19: Daisy Chaining

This can increase the maximum distance from the PC to the last panel in the chain to 4,000 ft (1,219.2 m).

The first panel is connected directly to the server using an MD-14U converter, while the second panel connects to the first panel. Additional panels are connected in the same way, one after another. The server identifies each panel on the RS-485 network by its address.

At each end of the data line, both where the panel connects to the computer and on the last panel in the network, a termination resistor of 100–120  $\Omega$  may be required. Apply the resistor across the L1 and L2 connections.



#### 6.2 TCP/IP Network Connection



This section applies to the AC-425IP-B model only.


The computer running the AxTraxNG software can communicate with the access control panels via a TCP/IP network. The connection settings are controlled within the AxTraxNG software.


AC-425x-B panels connect to the TCP/IP network (LAN or WAN) directly, using an onboard network module. When an access control panel network is connected using RS-485, up to 32 panels can be connected on each TCP/IP network.

#### 6.2.1 LAN and WAN Requirements

The devices can be connected to a TCP/IP network using any valid network address.

The AC-425IP-B panels connect to the TCP/IP network (LAN or WAN) directly, using an onboard network module. For each AC-425IP-B panel connected on a TCP/IP port, up to 31 subnetworked panels can be connected via an RS-485 bus, which means that one IP port can support up to 32 AC-425IP-B panels (Figure 20).





To connect to a TCP/IP network using AC-425 non-IP models, add Rosslare's MD-N32 TCP/IP to RS-232 gateway converter.

For more information on operating an MD-N32, refer to the MD-N32 User Manual.


Note

#### 6.2.2 LAN and WAN Requirements

The devices can be connected to a TCP/IP network using any valid network address.

Use a TCP/IP connection when a LAN network already exists. Figure 21 illustrates the connection of a single AC-425IP-B to a computer via a LAN network.





The maximum distance from the Ethernet port of the panel to the LAN/WAN connection is 100 m (330 ft).


When the TCP/IP connection is implemented over a WAN, it becomes possible to connect through the Internet. This makes it possible to control multiple access control panels worldwide, all from a single computer.

Before connecting a panel by TCP/IP connection for the first time, the AxTraxNG software must configure the device. Settings then remain stored in non-volatile memory on the device (see the AxTraxNG Software Manual).

When using an MD-N32, for a single panel, either an RS-232 cable or Rosslare's MD-14U RS-485 to RS-232 converter can be used.

To connect an MD-N32 to more than one panel (up to 32 panels), Rosslare's MD-14U RS-485 to RS-232 converter must be used. Connect the MD-14U between the RS-485 access control panel network and the MD-N32 converter (Figure 22).





# A. Declaration of Conformity

#### FCC ID = GCD-AC215x xxxx

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - This device may not cause harmful interference.
  - This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# B. Radio Equipment Directive (RED)

Under our sole responsibility that the following labeled AC-425-Bx, AC-425-DIN, AC-4215IP-Bx, and AC-425IP-DIN are tested to conform to the EU Radio Equipment Directive – RED 2014/53/EU – in electrical and electronic equipment.

# C. RoHS Directive

Under our sole responsibility that the following labeled AC-425-Bx, AC-4215-DIN, AC-425IP-Bx, and AC-425IP-DIN are tested to conform to the Restriction of Hazardous Substances (RoHS) directive – 2011/65/EU – in electrical and electronic equipment

# D. Limited Warranty

The full ROSSLARE Limited Warranty Statement is available in the Quick Links section on the ROSSLARE website at www.rosslaresecurity.com.

Rosslare considers any use of this product as agreement to the Warranty Terms even if you do not review them.



# Asia Pacific, Middle East, Africa

Rosslare Enterprises Ltd. Kowloon Bay, Hong Kong Tel: +852 2795-5630 Fax: +852 2795-1508 support.apac@rosslaresecurity.com

### United States and Canada

Rosslare Security Products, Inc. Southlake, TX, USA Toll Free: +1-866-632-1101 Local: +1-817-305-0006 Fax: +1-817-305-0069 support.na@rosslaresecurity.com

### Europe

Rosslare Israel Ltd. 22 Ha'Melacha St., P.O.B. 11407 Rosh HaAyin, Israel Tel: +972 3 938-6838 Fax: +972 3 938-6830 support.eu@rosslaresecurity.com

### Latin America

Rosslare Latin America Buenos Aires, Argentina Tel: +54-11-4001-3104 support.la@rosslaresecurity.com

China

Rosslare Electronics (Shenzhen) Ltd. Shenzhen, China Tel: +86 755 8610 6842 Fax: +86 755 8610 6101 support.cn@rosslaresecurity.com

### India

Rosslare Electronics India Pvt Ltd. Tel/Fax: +91 20 40147830 Mobile: +91 9975768824 sales.in@rosslaresecurity.com





 $0706 {-} 0960668 {+} 00$ 

# Product No.